Loria 6000

Air/water heat pump single service split system







	U057 11/04	7296_^ /2018	1633_E	EN_13
FR	NL	DE	EN	PL



Installation and commissioning manual

for professionals

to be kept by the user for future reference

atlantic-comfort.com

This device must be installed by qualified personnel with a certificate of capacity for the handling of refrigerants.

Cont	Contents						
Description of the equipment	Description of the equipment						
Packaging	Description						
Layout.12Installation and maintenance rules12Unpacking and reservations.12Positioning the refrigerant connections14	Installing the outdoor unit						
Refrigerant connection and filling the inRules and precautions.17Shaping the refrigeration pipes17Checks and connections18	installation with gas 17 Filling the installation with gas 20 Additional charge 23 Collecting refrigerant in the outdoor unit. 23						
Hydraulic connections	Filling and draining the installation 24 Overall hydraulic layout 25						
Electrical connections	Electrical connections - SELV						
Commissioning	Circulation pump operation 38 Floor drying mode 39						

Controller	
User interface	Start temperature calculation
Room thermostat (optional)	Regulation parameters
Information and troubleshooting	
Displaying information	Outdoor unit errors
Hydraulic unit errors	Safety thermostat
Maintaining the installation	
Hydraulic checks	Checking the outdoor unit
	Electrical checks
Maintenance	
Draining the hydraulic unit	Replacing fuses
Electrical wiring diagrams	
Electrical wiring (outdoor unit)	Electrical wiring (hydraulic unit - excluding connections made by the installer)
Quick-start procedure	
Commissioning check-list	Settings sheet
	Start-up data sheet
Instructions for the user	
ERP performance values	
ERP definition	Package sheet
ERP Specifications	

Packing list

Heat pump		Outdoor unit		Hydraulic unit	
Model	Atlantic (export)	Model	Ref.	Model	Ref.
Loria 6004	522911	WOYA060LFC	700169	Loria 6004	023001
Loria 6006	522912	WOYA060LFCA	700171		
Loria 6008	522913	WOYA080LFC or WOYA080LFCA	700170 or 700172	Loria 6006 - 6010	023000
Loria 6010	522914	WOYA100LFTA	700173		

Optional equipment

- *Wired room thermostat UA55* (ref. 076 310) for correcting the ambient temperature.
- *HP Pack (*ref. 602 231) for reporting consumption per use (Heating / DHW).
- *Dual circuit kit* (ref. 076 311) for connecting 2 heating circuits.
- *DHW kit* (ref. 076 312) for connecting a DHW tank (with built-in electrical back-ups).
- Cooling kit (ref. 076 313).
- **Sediment trap** (ref. 075 100) for protecting the heating circuit of the HP (to be placed on the heating return circuit).
- Modem cable bundle kit (ref. 075 120).
- Anti-vibration pads (ref. 523 574).
- White PVC floor support (ref. 809 532) or Black rubber floor support (ref. 809 536).
- Condensate drain pan (ref. 074 008).
- Container bottom tracer (ref. 809 644).

Scope

This heat pump provides:

- heating in winter,
- control of two heating circuits*,
- production of domestic hot water* (provided that combined with a DHW tank),
- cooling in summer* (for floor heating/cooling system or fan-coil unit).
- *: These options require the use of additional kits (see § "Optional equipment").

1 Description of the equipment

1.1 Packaging

- 1 package: Outdoor unit
- **1 package**: Hydraulic unit, filter valve, pressure gauge valve and outdoor sensor.

1.2 Definitions

- <u>Split</u>: The heat pump is formed by two elements (an outdoor unit to be installed outdoors and a hydraulic unit to be installed indoors).

- <u>Air/water</u>: The outdoor air is the energy source. This energy is transmitted to the heating water by the heat pump.
- <u>Inverter</u>: The speeds of the fan and the compressor are modulated to suit the heat requirements. This technology saves energy and permits operation with a single phase power supply, regardless of the power rating of the heat pump, by avoiding high current demands on start-up.
- <u>COP</u> (coefficient of performance): this is the ratio between the energy transmitted to the heating circuit and the electrical energy consumed.

1.3 **Specifications**

Model name Loria	l	6004	6006	6008	6010
Nominal heating performances (outdoor temperature/ initial temperature)					
Heat output					
+7 °C/+35°C - floor heating system	kW	4.00	6.00	7.50	10.42
-7 °C/+35°C - floor heating system	kW	4.10	5.00	5.90	7.94
+7°C/+45°C - LT radiator	kW	4.00	5.10	6.20	8.51
-7 °C/+45°C - LT radiator	kW	4.10	4.50	5.15	7.38
Power absorbed					
+7 °C/+35°C - floor heating system	kW	0.83	1.35	1.81	2.37
-7 °C/+35°C - floor heating system	kW	1.46	1.79	2.46	3.11
+7 °C/+45°C - LT radiators	kW	1.14	1.46	1.85	2.40
-7 °C/+45°C - LT radiator	kW	1.78	1.99	2.45	3.51
Coefficient of performance (COP) (+7°C/+ 35°C)		4.80	4.45	4.15	4.40
Electrical characteristics					
Voltage (50 HZ)	V		23	30	
Stand-by consumption	W	5/5	5 / 5	5 / 5.5	5 / 6
Nominal current / Maximum current of the appliance	А	4.5 / 11	6.3 / 12.5	8.1 / 17.5	10.9 / 18.5
Maximum current / Power of the electrical back-ups	A/ kW		13.0)5 / 3	
Power absorbed by the circulation pump (max. / average as per RT2012)	W		45	/ 24	
Actual power absorbed by the fan	W		4	9	
Maximum power absorbed by the outdoor unit	W	2530	2875	4025	4255
Hydraulic circuit					
Maximum operating pressure	MPa (bar)		0.3	6 (3)	
Available heating pressure at nominal point +7 °C / + 35 °C	MPa (bar)	0.064 (0.64)	0.05 (0.5)	0.036 (0.36)	0.021 (0.21)
Minimum allowed hydraulic flow rate	l/h	420		600	
Minimum/maximum flow rate of the hydraulic circuit at $4^\circ\text{C}<\!\Delta t<\!8^\circ\text{C}$ (nominal conditions)	l/h	430 / 860	650 / 1300	810 / 1620	1010 / 2020
Minimum recommended water volume per circuit (excl. HP) ¹ - Floor heating-cooling system - Cast iron / steel radiators - Dynamic radiator ²	 	15 25 36 ⁽²⁾	15 25 36 ⁽²⁾	28 46 49 ⁽²⁾	35 57 62 ⁽²⁾
Expansion vessel contents				8	
Miscellaneous					
Weight of hydraulic unit (empty/full of water)	Kg		37.5	/ 41.5	
Weight of the outdoor unit	Kg	41	41	42	60
Noise level at 1 metre ³ (hydraulic unit)	dB (A)		3	86	
Sound power level as per EN 12102 ⁴ (hydraulic unit)	dB (A)		4	4	
Noise level at 5 metres ³ (outdoor unit)	dB (A)	40	40	47	47
Sound power level as per EN 12102 ⁴ (outdoor unit)	dB (A)	62	62	69	69
Heating system operating limits					
Min./max. outdoor temperature	°C		-20	/ +35	
Max. water temperature for heating outgoing circuit	°C		5	55	
Min. water temperature for heating return circuit (heating mode)	°C		1	7	
Refrigerant circuit					
Diameters of the gas / liquid pipes	Inches	1/2 / 1/4	1/2 / 1/4	5/8 / 1/4	5/8 / 3/8
Factory charge of refrigerant R410A ⁵	q	1100	1100	1400	1800
Maximum operating pressure	MPa (bar)		4.15	(41.5)	
Min. / max. length of pipes ⁶ / max. length with additional charge ⁷	m		5 / 1	5 / 30	
Maximum level difference	m		2	20	

¹ Min. circulating water volume required for each circuit excl. HP volume: see additional information § 4.2, page 24.
² Water volume to be complied with, installation of a buffer required.

³ Sound pressure level at (x) m from the appliance, 1.5 m from the ground, free field, directivity 2.

⁴ The acoustic power is a measurement made in the laboratory of the power of

the noise emitted but contrary to the noise level, it does not correspond to the measurement of what is felt. ⁵ Refrigerant R410A in compliance with standard NF EN 378.1.

⁶ Factory charge of refrigerant R410A.

⁷ Taking into account the potential additional charge of refrigerant R410A (see § 3.5, page 23.



figure 1 - Dimensions in mm



figure 2 - Dimensions in mm







figure 4 - Ohmic value of the sensors (hydraulic unit -outdoor sensor)



figure 5 - Ohmic value of the sensors (outdoor unit)

1.4 Description

Coria 6004 and 6006 models Image: Coria 6004 and 6006 models Image: Coria 6004 and 6006 models

Key:

- 1. High performance propeller and low noise level.
- 2. Electrical motor with variable "inverter" operation.
- 3. Control lights and buttons.
- 4. Connection terminal blocks
- (power and interconnection).
- 5. Refrigerant storage cylinder.
- 6. 4-way valve.
- 7. Panels treated against corrosion.



- 8. Electronic expansion valve of the main circuit.
- 9. "Inverter" compressor acoustically and thermally insulated.
- 10. Refrigeration connection valves (flared connectors) with protective caps.
- 11. Holding tank with condensate drain hole.
- High-performance exchange surface evaporator; anti-corrosion treated hydrophilic aluminium blades and grooved copper tubes.



figure 6 - Components

Hydraulic unit

Key:

- 13. Electric box.
- 14. Controller / User interface (description, see § 7.1, page 40).
- 15. Circulation pump.
- 16. Initial heating flow.
- 17. Return heating flow.
- 18. Gas refrigeration connection.
- 19. Liquid refrigeration connection.
- 20. Safety valve.
- 21. Automatic air bleeder.
- 22. Expansion vessel.
- 23. Condenser (exchanger).
- 24. Electrical back-up.
- 25. Filter valve (supplied unassembled).
- 26. Valve (supplied unassembled) Pressure gauge / Bleed tap.
- 27. Flow meter.
- 28. HP outgoing sensor.
- 29. HP return sensor.
- 30. Reset button
 - (overheating safety device).



figure 8 - Components



figure 7 - Operating principle of a heat pump

1.5 Operating principle

The heat pump transmits the energy contained in the surrounding air into the residence to be heated.

The heat pump consists of four main elements, in which a refrigerant (R410A) circulates.

- In the evaporator (reference **12**, *figure* 6): The energy is taken from the surrounding air and is transmitted to the refrigerant. Because it has a low boiling point, it changes from liquid state to vapour state, even in cold weather (down to -15 °C outdoor temperature).
- In the compressor (reference **9**, *figure 6*): The vaporised refrigerant is brought to high pressure and takes on more calories.
- In the condenser (reference **23**, *figure 6*): The energy in the refrigerant is transmitted to the heating circuit. The refrigerant returns to its liquid state.
- In the expansion valve (reference **8**, *figure 6*): The liquefied refrigerant is brought back to low pressure and returns to its initial temperature and pressure.

The heat pump has a regulator that controls the indoor temperature based on the measurement of the outdoor temperature, known as weather-dependent control. The room thermostat (optional) corrects the weatherdependent setpoint.

The hydraulic unit is equipped with an electrical backup system, which is designed to provide additional heat during the coldest periods.

Regulation functions

- The initial temperature of the heating circuit is controlled by the weather-dependent setpoint.
- The power of the outdoor unit is modulated according to the need via the "inverter" compressor.
- Control of the electrical back-up.
 - > Additional heating when the HP alone is insufficient.
 - Assist mode.
- The daily timer programme enables you to define the periods for comfortable or reduced ambient temperature.
- Switching between summer/winter operation is automatic.
- Room thermostat*: The room thermostat corrects the weather-dependent setpoint.
- Domestic hot water*
- Protection functions
- Compressor protection via heating back-up (see § 6.2.4, page 39).
- Heat exchanger protection via heating back-up.
- Legionella cycle for domestic hot water.
- Minimum flow detection.
- Frost protection.
- Electrical back-up safety thermostat.

* When the heat pump is equipped with options and associated kits.

• Domestic hot water (DHW) operating principle (If the installation is equipped with a DHW tank).

Two domestic hot water (DHW) temperatures can be set:

- Comfort temperature (\blacksquare 🔆) and
- Reduced temperature (**ECO**)

(see **user interface description** *page 40* or room thermostat):

The DHW programme (**PROG**) is set by default to a comfort temperature ($\stackrel{\sim}{\sim}$) according to 2 pre-set phases (see "DHW timer programme (1)", page 45) and a reduced temperature (**ECO**) for the rest of the day, which optimises electricity consumption while ensuring comfortable levels of hot water and heating.

The production of domestic hot water (DHW) is triggered when the temperature in the tank falls 7°C below the temperature setpoint.

The heat pump produces domestic hot water (DHW), which is then heated further, if required, by the electrical back-up system inside the tank.

To ensure that the DHW setpoint is reached, the electrical back-up system must be left on.

DHW production takes priority over heating; nevertheless the production of DHW is controlled by cycles that control the times assigned to the heating and the production of DHW in the event of simultaneous demand.

A DHW boost function is available (on the user interface: user level \checkmark , setting "95", page 47) or on the room thermostat page 41. This DHW boost is used to heat the DHW to the comfort temperature at any time of day. The boost function is cancelled automatically when the demand for hot water has been met.

Legionella cycles can be programmed.

• Dynamic radiators or fan-coil heaters with integrated control system

Do not use a room thermostat in the zone concerned.

2 Layout

2.1 Installation and maintenance rules

The appliance must be installed and maintained by an approved professional in accordance with the prevailing regulations and code of practice, in particular:

2.2 Unpacking and reservations

2.2.1 Acceptance

In the presence of the carrier, carefully inspect the general appearance of the appliances and check that the outdoor unit has not been placed in a horizontal position.

In the event of disagreement, write to the carrier within 48 hours mentioning all reserves and send a copy of this letter to the After Sales Department.

2.2.2 Handling

The outdoor unit must not be in a horizontal position during transport. Transport in a horizontal position may damage the appliance by moving the refrigerant and damaging the compressor's suspensions. **Damage caused by transportation in a horizontal position is not covered by the warranty**.

If necessary, the outdoor unit may be tilted during manual handling (to go through a door or use a staircase).

This operation must be conducted very carefully and the appliance must be immediately restored to the upright position.

2.2.3 Containing the refrigerant circuits

All refrigerant circuits are susceptible to contamination from dust and moisture. If such pollutants enter the refrigeration circuit, they can affect the reliability of the heat pump.

- Please ensure correct containment of the connections and refrigerant circuits (hydraulic unit, outdoor unit).
- In the case of subsequent failure and after inspection, the detection of moisture or foreign objects in the compressor oil would systematically make the warranty null and void.
- Check upon receipt that the refrigeration circuit caps and connections mounted on the hydraulic unit and outdoor unit are properly sealed and locked (cannot be loosened with bare hands). If this is not the case, tighten them using a wrench.
- Also check that the refrigerant connections are sealed (plastic caps or tubes crushed at the ends and brazed). If the caps must be removed during installation (for example tubes cut), reposition them as quickly as possible.

2.2.4 Accessories provided



figure 9 - Accessories provided with the hydraulic unit





2.3 Positioning the refrigerant connections

☞ ⚠ Manipulate the pipes and pass through slabs or walls with protective plugs in place or after brazing.



figure 11 - Recommended example of refrigerant connections layout

2.4 Installing the outdoor unit



Keep the protective caps or brazed ends <u>until</u> <u>commissioning the product.</u>

The outdoor unit and the hydraulic unit must only be connected using copper connections (refrigerating grade), insulated separately.

Comply with with the pipe diameters.

Comply with the maximum and minimum distances between the hydraulic unit and the outdoor unit; the performance and service life guarantees depend on this.

The minimum length of the cooling connections is 5 m for correct operation.

The appliance's warranty will become void if it is applied with cooling connections that are shorter than 5 m (tolerance +/-10%).

If the refrigeration connections are exposed to weathering or UV rays and the insulation is not UV-resistant, protection must be provided.

2.4.1 Installation precautions

- The outdoor unit must only be installed outdoors. If a shelter is required, it must have broad openings on all 4 walls and comply with the installation clearances (*figure 12*).
- Choose the installation site after talks with the customer.
- Prioritise a site that is sunny and sheltered from strong cold predominant winds (mistral, tramontane, etc.).
- The unit must be easily accessible for future installation and maintenance work (*figure 12*).
- Ensure that the connectors can be easily connected to the hydraulic unit.
- The outdoor unit can be exposed to bad weather, however avoid installing it in places where it will become dirty or have excessive water dripping onto it (for example under a leaky drainpipe).
- Water may be released from the outdoor unit when in operation. Do not install the appliance on a terrace; install it in a well-drained location (bed of gravel or sand). If installed in a region where the temperature

250 mm Minimum

figure 12 - Minimum installation clearances around the outdoor unit

300 mm Minimum may drop below 0°C for a long period of time, check that the ice does not cause any danger. A drainage pipe can also be connected to the outdoor unit (see *page 15*).

- Nothing should obstruct the air from circulating through the evaporator and out of the fan (*figure 12*).
- Keep the outdoor unit away from sources of heat or inflammable products.
- Ensure that the appliance does not disturb neighbours or users (noise level, draughts caused, low temperature of the air blown causing a risk of freezing plants in its path).
- The surface on which the outdoor unit is mounted must:
- be permeable (earth, gravel bed...),
- support its weight comfortably,
- allow for secure attachment,
- not transmit any vibration to the residence. Antivibration pads are available as an optional extra.
- The wall bracket cannot be used in conditions likely to transmit vibrations, where installation on the ground is preferred.

2.4.2 Positioning the outdoor unit

The outdoor unit must be raised by at least 50 mm from the ground. In snowy regions, this height must be increased but must not exceed 1.5 m (H - *figure 13*).

- Fasten the outdoor unit using screws and elastic tightening or toothed lock washers to prevent them from coming loose.
 - Caution: In regions with heavy snowfall, if the inlet and outlet of the outdoor unit are blocked with snow, this may cause heating difficulties and result in a breakdown. Build a canopy or position the unit on a high stand (local configuration).
- Set the unit on a sturdy base to minimise impacts and vibrations.
- Do not set the unit directly on the ground as this may generate disruptions.

2.4.3 Connecting a condensate drain hose

(figure 13).

The outdoor unit can generate a large volume of water (called condensate).

If the use of a drain hose is imperative: Install the condensate drain pan (**BR**) (optional, see *page 4*). Use the elbow provided (**C**) and connect a hose of 16 mm diameter to evacuate the condensates.

Use the plug(s) supplied (\mathbf{B}) to plug the orifice of the condensate drain pan.

Provide for the gravitational discharge of the condensates (waste water, rainwater, gravel bed).

☞ If the appliance is installed in a region where the temperature may fall below 0°C for long periods, fit the drain hose with a trace heater to prevent it from icing over. The trace heater must not only heat the drain hose but also the bottom of the appliance's condensate drain pan.



* In regions subject to frequent snow, (H) must be greater than the average snow layer.





figure 13 - Positioning the outdoor unit, discharging condensates

2.5 Installing the hydraulic unit

2.5.1 Installation precautions

- Choose the installation site after talks with the customer.
- The room where the appliance operates must comply with the regulations in force.
- To ease maintenance operations and provide access to the various parts, sufficient space should be left around the hydraulic unit.
- In accordance with EN 378-1 -2017 standard (Refrigerating systems and heat pumps Safety and environmental requirements), the system's hydraulic unit and all refrigeration connections passing through inhabited areas must comply with the minimum room volume requirements shown hereafter.

The minimum volume of a room (in m^3) is calculated using the formula: "fluid fill load" (in kg) / 0.39.

Alternatively, you must ensure that:

- the location has natural ventilation through another room where the combined volume of the two rooms is greater than "liquid fill load" (in kg) / 0.39 kg/m³. The opening between the two rooms must have a door clearance of at least 1 cm.

- or that the location is mechanically ventilated.

- Be careful to keep the heat pump awav from inflammable gas during installation. particular brazing. in when it requires The appliances are not fireproof and should therefore not be installed in a potentially explosive atmosphere.
- To avoid condensation inside the condenser, remove the refrigerant circuit caps **only when positioning the refrigerant connections**.

- If the refrigerant connection is only made at the end of the installation, ensure that the refrigerant circuit caps* remain in place and tight throughout the installation process.

* (side of the hydraulic unit and side of the outdoor unit)

- After any intervention on the refrigeration circuit and before final connection, replace the caps in order to avoid any pollution from the refrigeration circuit (sealing using tape is prohibited).

2.5.2 Positioning the hydraulic unit

- Secure the support (4 screws and plugs) to a flat, sturdy wall (not a light-weight partition) ensuring that it is correctly levelled.
- Hook the appliance onto its support.



figure 15 - Minimum installation clearances around the hydraulic unit



figure 14 - Mounting bracket

3 Refrigerant connection and filling the installation with gas

☞ This appliance uses refrigerant R410A.

Comply with the legislation for handling refrigerants.

3.1 Rules and precautions

- Connections must be made on the day of the filling the installation with gas (see § 3.4.3, page 22).
- Tooling
- Pressure gauge kit (*Manifold*) with hoses exclusively reserved for HFCs (Hydrofluorocarbons).
- Vacuum gauge with isolation valves.
- Special HFC vacuum pump (use of a traditional vacuum pump is authorised if and only if it is fitted with a non-return valve on the suction side).
- Flaring tool, pipe-cutter, Deburrer, Wrenches.
- Approved refrigerant detector (sensitivity 5g/year).
 - The use of tools that have been in contact with HCFCs (R22 for example) or CFCs is prohibited.
 - The manufacturer shall not be held liable with regard to the warranty if the above instructions are not complied with.
- Flared connections
 - Lubrication with mineral oil (for R12, R22) is prohibited.
- Only lubricate with polyolester refrigeration oil (POE). If POE oil is not available, fit without lubrication.



• Brazing on the refrigeration circuit (if necessary)

- Silver brazing (40% minimum recommended).
- Brazing with a dry nitrogen stream only.
- Important notes:
- After any intervention on the refrigeration circuit and before final connection, replace the caps in order to avoid any pollution from the refrigeration circuit.
- To eliminate any filings in the pipes, use dry nitrogen to avoid introducing any humidity that may adversely affect the appliance's operation. In general, take every precaution to avoid humidity penetrating the appliance.
- Insulate the gas and liquid pipes to avoid condensation. Use insulating sleeves that resist temperatures of over 90°C. In addition, if the level of humidity around the refrigerating pipes could exceed 70%, protect the latter with insulating sleeves. Use an insulating material thicker than 15mm if the humidity level reaches 70~80%, and an insulating material thicker than 20mm if the humidity level exceeds 80%. If the recommended thicknesses are not complied with under the conditions described above, condensation will form on the surface of the insulation material. Finally, use

insulating sleeves with a thermal conductivity equal to 0.045 W/mK or less when the temperature is 20°C. The insulation must be impermeable to prevent steam from passing during the defrosting cycles (glass wool is prohibited).

3.2 Shaping the refrigeration pipes

3.2.1 Bending

The refrigeration pipes must be shaped only on a bending machine or with a bending spring in order to avoid any risk of crushing or breakage.

Warning!

- Remove the nearby insulation before bending the tubes.
- Do not bend copper to an angle of more than 90°.
- Do not bend tubes more than 3 times at the same point to prevent the pipe from splitting (hardening of the metal).

3.2.2 Creating the flarings

- Cut the pipe to an appropriate length with a pipe-cutter without deforming it.
- Carefully deburr it, holding the pipe downwards to avoid introducing filings into the pipe.
- Remove the flare nut from the connector on the valve to be connected and thread the tube through the nut.
- Flare it and leave the tube protruding from the flaring tool.
- After flaring, check the condition of the face (L). This must not show any scratches or traces of fracturing. Also check the dimensions (**B**).



~ ~ .	Dimensions in mm				
Ø of pipe	L	B º/ _{-0.4}	С		
6.35 (1/4")	1.8 to 2	9.1	17		
9.52 (3/8")	2.5 to 2.7	13.2	22		
12.7 (1/2")	2.6 to 2.9	16.6	26		
15.88 (5/8")	2.9 to 3.1	19.7	29		

figure 16 - Flaring for flare connections

3.3 Checks and connections

- The refrigeration circuit is very sensitive to dust and humidity: check that the area around the connection is clean and dry before removing the caps protecting the refrigeration connectors.
- Blowing indicator value: 6 bar for at least 30 seconds for a 20 m connection.

Gas connection control (large diameter)).

① Connect the gas connection to the outdoor unit. Blow dry nitrogen into the gas connection and observe its end:

- If water or impurities emerge, use a new refrigerant connection.

Otherwise, perform the flare and immediately connect the refrigerant connection to the hydraulic unit.

Liquid connection control (small diameter)).

(3) Connect the liquid connection to the hydraulic unit.

- Blow dry nitrogen into the **gas connection condenser liquid connection assembly** and observe its end (side nearest the outdoor unit).
- If water or impurities emerge, use a new refrigerant connection.

- Otherwise, perform the flare and immediately connect the refrigerant connection to the outdoor unit.

Note:

- Take particular care when positioning the tube opposite its connector so as not to risk damaging the threads. A correctly aligned connector can be fitted easily by hand without much force being required.
- Depending on the case, connect an adapter (reducer) 1/4"- 3/8" or 1/2"- 5/8" (see figure 19, page 19).
- Comply with the indicated tightening torques (figure 18).



figure 17 - Checking refrigeration connections



figure 18 - Tightening torques

Heat pump model		Loria 60	04, 6006	Loria 6008		Loria	Loria 6010	
		gas	liquid	gas	liquid	gas	liquid	
Outdoor unit	connections	1/2" 1/4" 5/8" 1/4" 5/8"				3/8"		
	Diameter	(D1) 1/2"	(D2) 1/4"	(D1) 5/8"	(D2) 1/4"	(D1) 5/8"	(D2) 3/8"	
	Minimum length (L)	(L) 5						
Refrigerating	Maximum length* (L)	h* (L) 15						
connections	Maximum length** (L)	** (L) 30						
	Maximum level difference** (D)	20						
Male-female a	ndapter (reduction)	(R1) (R2) (R2) Without (R2) Without 1/2" - 5/8" 1/4" - 3/8" Without 1/4" - 3/8" Without				nout		
Hydraulic uni	t connections	5/8"	3/8"	5/8"	3/8"	5/8"	3/8"	

*: Without additional charge of R410A.

**: Taking account of any additional charge (see 3.5, page 23).



figure 19 - Refrigerating link connection (accepted diameters and lengths)

3.4 Filling the installation with gas

- This operation is only to be carried out by qualified fitters in compliance with the legislation for the handling of refrigerants.
- ☞ Creating a vacuum with a vacuum pump is essential (see ANNEX 1).
- ☞ Do not use equipment that has previously been used with a refrigerant other than a HFC.
- ☞ Remove the refrigerant circuit caps only when making the refrigerant connections.

\triangle If the outdoor temperature is below +10°C:

- The 3-vacuum method must be used. (see ANNEX 2).

- A dehydrator filter should be installed (<u>highly</u> <u>recommended</u> if the outdoor temperature is below +5°C).

ANNEX 1

Method for calibrating and checking a vacuum pump

- Check the oil level of the vacuum pump.
- Connect the vacuum pump with the vacuum gauge as shown in the diagram.
- Pump down for 3 minutes.
- After 3 minutes, the pump reaches its vacuum threshold value and the vacuum gauge needle stops moving.
- Compare the obtained pressure with the value in the table. Depending on the temperature, this pressure must be less than the value indicated in the table.
- => If this is not the case, replace the seal, hose or pump.

T °C	5°C <t<10°c< th=""><th>10°C<t<15°c< th=""><th>15°C < T</th></t<15°c<></th></t<10°c<>	10°C <t<15°c< th=""><th>15°C < T</th></t<15°c<>	15°C < T
Pmax - bar - mbar	0.009 9	0.015 15	0.020 20

ANNEX 2

3-vacuum method

- Connect the high pressure hose from the manifold to the load orifice (gas connection). A valve must be mounted on the hose from the vacuum pump in order to isolate it.

a) Pump down to the desired value and maintain this value for 30 min (see table in ANNEX 1),



b) Stop the vacuum pump, close the end valve of the service hose (yellow), connect this hose to the expansion valve of the nitrogen cylinder, inject 2 bars then close the hose valve,



c) Reconnect the hose to the vacuum pump, turn on and gradually open the hose valve.



- d) Repeat this operation at least three times.
- Reminder: it is strictly forbidden to perform these operations with the refrigerant.

3.4.1 Leak test

- Remove the protective plugs (**B**) from the charging hole (*Schrader*) in the gas valve (large diameter).
- Connect the high pressure hose from the *Manifold* to the load orifice (*figure 20*).
- Connect the cylinder of nitrogen to the *Manifold* (use only type U dry nitrogen).
- Flow the pressurised nitrogen (10 bar maximum) in the refrigerant circuit (gas connection – condenser
 liquid connection assembly).
- Leave the circuit under pressure for 30 minutes.



- Search for leaks with a leak detector product, repair and repeat the test.



- When the pressure is stable and any leakage is excluded, empty the nitrogen to produce a pressure greater than atmospheric pressure (0.2 to 0.4 bar).



figure 20 - Connecting the hose on the gas valve

3.4.2 Pump down

 \triangle The 3-vacuum method (ANNEX 2) is highly recommended for all installations, especially when the outdoor temperature is below 10°C.

- If necessary, calibrate the *Manifold* pressure gauge(s) to 0 bar. Adjust the vacuum gauge to the atmospheric pressure (≈ 1013 mbar).
- Connect the vacuum pump to the *Manifold*. Connect a vacuum gauge if the vacuum pump is not equipped with this.



- Pump down until the residual pressure* in the circuit falls below the value given in the following table. (* measured with the vacuum gauge).

T °C	5°C <t<10°c< th=""><th>10°C<t<15°c< th=""><th>15°C < T</th></t<15°c<></th></t<10°c<>	10°C <t<15°c< th=""><th>15°C < T</th></t<15°c<>	15°C < T
Pmax - bar - mbar	0.009 9	0.015 15	0.020 20

- Let the pump continue to operate for a further 30 minutes after reaching the required vacuum.

- Close the *Manifold* valve, then stop the vacuum pump without disconnecting any of the hoses in place.

3.4.3 Filling the installation with gas

⚠ If an additional charge is required, add the additional charge before filling the hydraulic unit with gas. See § "Additional charge", page 23.

- Remove the access plugs (A) from the valve

controls.

- First open the liquid valve (small valve) fully and then the gas valve (large valve) using a hex/Allen key (counter-clockwise direction) without forcing excessively against the stop.
- Quickly remove the hose from the *Manifold*.
- Refit the 2 original caps (ensure that they are clean) and tighten them to the recommended tightening torque as shown in the table *figure 18, page 18.* The seal is produced in the caps via a metal-on-metal contact only.

The outdoor unit does not contain any additional refrigerant, enabling the installation to be drained.

Drain by flushing is strictly forbidden.

3.4.4 Final sealing test

The sealing test must be performed with a certified gas detector (sensitivity 5g/year).

Once the refrigerating circuit has been filled with gas as described above, check all of the installation's refrigerating connectors for leaks (*Loria 6004, 6006 models*: 6 connections - *Loria 6008 model*: 5 connections - *Loria 6010 model*: 4 connections). If the flarings have been made correctly, there should be no leaks. Where necessary, check the tightness of the refrigerant valve caps.

- If there is a leak:
- Bring the gas into the outdoor unit (pump down). The pressure should not drop below atmospheric pressure (0 bar as read at the *Manifold*) so as not to contaminate the recovered gas with air or moisture.
- Refit the faulty connection,
- Repeat the commissioning procedure.

3.5 Additional charge

Loria 6004, 6006 a 6008	nd	25 g of R410A per extra metre		
Length of the connection	ons	15 m		30 m max.
Additional charge	none		375 g	
Loria 6010	40 g of R410A per extra metre			
		pe	r extra r	netre
Length of the connections	15	ре т	r extra r 16 m	netre 30 m max.

The outdoor unit charge corresponds to the maximum distances between the outdoor unit and the hydraulic unit defined in *figure 19, page 19*. For greater distances, an additional charge of R410A is required. The additional charge depends, for each type of appliance, on the distance between the outdoor unit and the hydraulic unit. The additional charge of R410A must only be added by a qualified specialist.

• Example for Loria 6004:

An outdoor unit at a distance of 17 m from the hydraulic unit will require an additional charge of:

Additional charge = $(17 - 15) \times 25 = 50 \text{ g}$

The charge must be introduced after pump down and before the hydraulic unit is filled with gas, as follows:

Disconnect the vacuum pump (yellow hose) and replace with a cylinder of 410A <u>in the liquid drawing position</u>.

- Open the tap of the cylinder.
- Bleed the yellow hose by loosening it slightly on the *Manifold*side.
- Place the cylinder on scales with a minimum accuracy of 10g. Note the weight.
- Carefully open the blue tap slightly and monitor the value displayed on the scales.
- As soon as the value displayed has dropped by the value of the calculated additional charge, close the cylinder and disconnect it.
- Quickly disconnect the hose from the appliance.
- Add the gas to the hydraulic unit.

☞ Warning!

- Only use R410A!
- Only use tools suitable for R410A (pressure gauge kit).
- Always charge in liquid phase.
- Do not exceed the maximum length or difference in height.



figure 21 - Gas cylinder R410A

3.6 Collecting refrigerant in the outdoor unit

- Ensure that all electrical power supplies have been cut off before starting work.
- Stored energy: after disconnecting the power supplies, <u>wait 1 minute</u> before accessing the internal parts of the equipment. Perform the following procedures to collect the refrigerant. Ensure that the pressure gauge kit *Manifold*) has been previously installed.
- **1** Power off the appliance and its peripherals (hydraulic unit, outdoor unit, back-up system(s)).
- 2- Remove the front panel. Open the power control box. Switch the **DIP SW1** of the interface board to **ON**.
- 3- Power ON the appliance and its peripherals (the green and red LEDs on the board start flashing; 1 sec. ON / 1 sec. OFF repeated) => The pump starts up. The outdoor unit starts in the cold mode for approximately 3 minutes after it is switched on.
- **4- Immediately after the outdoor unit starts**: close the liquid valve on the outdoor unit.
- 5- Gradually close the gas valve on the outdoor unit so that it is closed when the relative pressure drops below 0.02 bar as read at the *Manifold* (about 1 or 2 minutes after closing the liquid valve), while the outdoor unit keeps running.
- 6- Cut off the main power supply.
- 7- The refrigerant collecting operation is complete.

Note:

- When the heat pump is operating, the pump down operation may not be activated, even if the **DIP SW 1** switch is set to **ON**.
- Do not forget to return the **DIP SW 1** switch to **OFF** after the pump down operation.
- If the pump down operation fails, try the procedure again by turning off the machine and opening the "gas" and "liquid" valves. After 2 to 3 minutes repeat the pump down operation.



figure 22 - Location of DIP switches and LEDs on the hydraulic unit interface board

4 Hydraulic connections

Overview

The connection must comply with good engineering practices according to the regulations in force.

<u>Reminder</u>: Make the assembly seals according to good engineering practices in force for plumbing work:

- Use suitable seals (fibre seals, O rings).
- Use Teflon or hemp tape.
- Use sealant (synthetic as required).

<u>Reminder</u>: The presence on the installation of a CB disconnection function (IEC 61770), designed to avoid heating water from returning to the drinking water network, is required by articles 16.7 and 16.8 of the Standard Departmental Sanitation Rules.

Glycol must be used if the initial temperature is less than 10°C (cooling on the fan-coil heater). If water containing glycol is used, carry out an annual check of the quality of the glycol. Use monopropylene glycol only. **Never use monoethylene glycol.**

- In certain installations, the presence of different metals can cause corrosion problems; in this case, the formation of metal particles and sludge in the hydraulic circuit is seen. Use a corrosion inhibitor in the proportions recommended by its manufacturer.
- Please refer to the section entitled "Treatment of domestic and heating water" in our price catalogue.
 - It is also necessary to ensure that the treated water does not become aggressive.

4.1 Rinsing the installation

Before connecting the hydraulic unit to the installation, **rinse the heating system correctly** to eliminate the particles that could compromise the correct operation of the appliance. Provide a sufficiently large decanting pot with a drain on the return line from the heat pump and at the lowest point in the system in order to collect and remove the impurities.

Do not use solvents or aromatic hydrocarbons (petrol, paraffin, etc.).

Add an alkaline product to the water and a dispersant. Rinse the installation several times before final filling.

4.2 Connections

The heating circulating pump is built into the hydraulic unit.

The diameter of the pipe between the hydraulic unit and the heating manifold must be at least equal to 1 inch (26x34 mm). Tightening torque: 15 to 35 Nm.

• Water volume:

To maintain a comfortable level for the user, please comply with the minimum water volume per circuit (see table, $\S1.3$, page 5).

<u>Circuit equipped with dynamic radiators</u>: a buffer must be installed and the minimum volume must comply with the specifications (\S *1.3*).





• Flow requirements:

- Calculate the diameter of the pipes according to the flow rates and the lengths of the hydraulic circuits.

The appliance will operate correctly if the flow range complies with the specifications (see table, §1.3, page 5). For this purpose, the HP is equipped with a flow meter that ensures a sufficient minimum flow in the heat exchanger. If flow is insufficient (§1.3), the appliance will show a safety error.

- ☞ For an installation with thermostat valves (floor heating system or radiator), a differential (bypass) valve must be installed or a valve-free hydraulic loop must be maintained far enough away from the HP to guarantee a minimum flow rate (§1.3).
- Connect the pipe of the central heating to the hydraulic unit respecting the direction of flow.
- Install the valve filter on the heating return circuit in the

manner suggested (ref. VF, figure 23).

- Install the "pressure gauge" valve on the heating outgoing circuit in the manner suggested (ref. **V-M**).
- We strongly recommend installing the sediment trap (optional) on the heating return circuit to collect and remove the impurities (ref. Dec).
- Use union connectors to facilitate removing the hydraulic unit.
- Prioritise connector hoses to avoid transmitting noise and vibrations to the building.



figure 24 - Connecting the floor heating system

- Connect the drains from the drain valve and the safety valve to the main sewer system.

Verify the correct functioning of the expansion system. Control the vessel pressure (precharge 1 bar) and the safety valve setting.

4.2.1 Connecting to an underfloor heating circuit

figure 24

To ensure that the installation operates correctly on a floor heating system equipped with thermostat valves, provide a bypass (**A**) or an open loop (**B**) to guarantee the minimum flow rate required (see "1.3 Specifications", page 5).

In the event of non-compliance with the minimum flow rate, the HP shuts down (error 131 - see "8.2 Hydraulic unit errors", page 49).

4.2.2 Connecting to a dynamic radiator or fan-coil heater circuit

A buffer must be installed on the dynamic radiator return circuit (comply with the **minimum circulating water volume** (see table, §1.3). Also refer to "Overall hydraulic layout", page 26 to page 28).

Circ		
combined (HC2)	direct (HC1)	
UFH-R	DynR or FC	Buffer on HC1 return
DynR or FC	Radiators	Buffer on return of
DynR or FC	DynR or FC	2 circuits

4.3 Filling and draining the installation

Check the attachment of the pipes, that the connectors are tight and that the hydraulic unit is stable.

Check the water flow direction and that all of the valves are open.

Fill the installation.

Do not operate the circulating pump while filling. Open all the drain valves in the installation to remove the air contained in the pipes.

Close the drains and add water until the pressure of the hydraulic circuit reaches 1.5 bar.

Check that the hydraulic circuit is drained correctly.

Check there is not a leak.

After the "Start-up" stage (see *page 38*), once the machine has started, purge the hydraulic unit again (see § 6.2.3, *page 38*).

Precise filling pressure is determined by the manometric head of the installation.

4.4 Overall hydraulic layout

Installation configuration - see page 44

Parameter 🔂 4 - 1 (1 heating circuit)



Installation configuration - see page 44 Parameter 🔂 4 - 3 (2 heating circuits with decoupling cylinder)



Installation configuration - see page 44





Installation configuration - see page 44

Parameter 🔂 **4 - 3 (2 heating circuits with decoupling cylinder)** Parameter 🔂 **5 - 1 (DHW tank)**



5 Electrical connections

5.1 Electrical power connections (LV)

Always check that the electric power supply is switched off before works.

5.1.1 Characteristics of the electrical power supply

The electrical installation must be conducted in accordance with the regulations in effect and in particular:

The electrical connections will only be made when all of the other assembly operations (attachment, assembly,...) have been carried out.

Warning!

The contract taken out with the energy supplier must be sufficient to cover the power of the heat pump as well as the sum of the power requirements of all of the appliances likely to be operated at the same time. When the power is too low, check with the energy provider the value subscribed to in your contract.

Never use a socket for the power supply.

The heat pump must be directly powered (without external switch) by dedicated lines that are protected from the electrical housing by bipolar circuit breakers dedicated to the heat pump, curve C for the outdoor unit, curve C for the electrical DHW back-ups (see tables *page 31*).

The electrical installation must be equipped with a differential protection of 30 mA.

This appliance is designed to operate under a nominal voltage of 230 V +/- 10%, 50 Hz.

5.1.2 General remarks on electrical connections

It is essential to maintain the phase-neutral polarity when making the electrical connections.

Rigid wires are preferable for fixed installations, particularly in a building (see *page 31*).

Clamp the cables using cable clamps to avoid any accidental disconnection of the conductive wires.



Connection to Earth and Earth bonding continuity are essential.

Connecting to screw terminals

☞ Use of ring terminals or tips is prohibited.

- Always choose a rigid wire that complies with current standards.
- Strip the end of the wire over a length of around 25 mm.
- With round nosed pliers, make a loop with a diameter that corresponds to the terminal's tightening screws.
- Tighten the terminal screw on the loop very firmly. Insufficient tightening can cause overheating, leading to breakdown or even a fire.



Connecting to spring terminals

- Strip the end of the wire over a length of around 10 mm.
- Push the spring with a screwdriver so that the wire enters the cage.
- Slide the wire into the opening provided for this purpose.
- Remove the screwdriver and then check that the wire is jammed in the cage by pulling on it.



5.1.3 Overview of the electrical connections

The electrical diagram of the hydraulic unit is detailed in page 58.



figure 25 - Overall layout of the electrical connections for a single installation (1 heating circuit)

5.1.4 Cable section and protection rating

Trovide a disconnection means for all power supplies according to the installation rules (EN 60335-1).

- The cable sections are given for information purposes only and <u>do not exempt the installer from</u> <u>checking that these sections correspond to the requirements and comply with the prevailing standards</u> (also take into account the connection length).
- Always check that the electric power supply is switched off before works.

Heat pi	ımp (HP)	230 V - 50 Hz electric power supply		
Model	Max. power absorbed	Cable ⁽¹⁾ (phase, neutral, earth)	Curve C circuit breaker size	
Loria 6004	2530 W	$2 \times 1 5 \text{ mm}^2$	16 Δ	
Loria 6006	2875 W	5 X 1.5 IIIII	10 A	
Loria 6008	4025 W	$2 \times 2 E \text{ mm}^2$	20.4	
Loria 6010	4255 W	3 X 2.5 IIIII-	20 A	

• Power supply to outdoor unit

• Interconnection between the outdoor unit and the hydraulic unit

Hydraulic unit		Power supply	Outdoor unit
Model	Max. power absorbed	Cable ⁽¹⁾ (phase, neutral, earth, communication bus)	Model
Loria 6004 <=> 6008	100 \//	4 x 1 5 mm ²	WOYA0x0LFC(A)
Loria 6010		4 X 1.5 11111-	WOYA100LFTA
- Bower cupply to the al	actrical back upor		

Power supply to the electrical back-ups:

Heat pump	Electrica	al back-ups	Power supply to the electrical back-ups	
Model	Power	Nominal current	Cable ⁽¹⁾ (phase, neutral, earth)	Curve C circuit breaker size
Loria 6004 <=> 6010	3000 W	13 A	3 x 1.5 mm ^{2 (2)}	16 A

⁽¹⁾ Cable type 60245 IEC 57 or 60245 IEC 88.

⁽²⁾ <u>Note</u>: The cable used to connect the electrical back-up must not exceed $3 \times 2.5 \text{ mm}^2$ (the spring terminal cannot receive wires with a diameter exceeding 2.5 mm²).

5.1.5 Electrical connections on the outdoor unit side

To access the connector terminals:

- Loria 6004, 6006 and 6008 models
- Remove the cover (figure 26).



figure 26 - Accessing the outdoor unit's terminal block (Loria 6004, 6006, 6008)

- Loria 6010 model
- Remove the front panel, remove the cover.



figure 27 - Accessing the outdoor unit's terminal block (Loria 6010)

- Make the connections according to the diagram (*figure 28*).
- Use cable clamps to prevent the conductors frombeing disconnected accidentally.



figure 28 - Connections to the outdoor unit's terminal block

5.1.6 Electrical connections on the hydraulic unit side

To access the connector terminals:

- Remove the front panel (3 screws)

- Rotate and open the electric box (2 + 3 screws).

- Make the connections according to the diagram (*figure 32*).



figure 29 - Removing the front panel & accessing the electric box



figure 30 - Electric box: Description

- Do not place the sensor lines and the sector supply lines in parallel in order to avoid interferences due to voltage points in the sector supply.
- Do not lay the electrical cables on piping (water and refrigerant pipes).
- Ensure that all of the electrical cables are housed in the spaces provided (*figure 31*).



figure 31 - LV cable bushing



figure 32 - Connection to the terminal board (hydraulic unit)

Interconnection between the outdoor unit and the hydraulic unit

Comply with the correspondence between the markings on the hydraulic unit's terminals and those on the outdoor unit when connecting the interconnection cables (*figure 32*).

An incorrect connection can cause the destruction of one of the units.

Electrical back-ups

Connect the power supply of the back-ups to the mains supply board (*figure 32*).

• Domestic hot water tank (optional)

If the installation is equipped with a DHW tank (with electrical back-up):

- Please refer to the instructions supplied with the DHW kit.
- Please refer to the instructions supplied with the DHW tank.

• Contract with the power supplier.

The heat pump's operation can be controlled to suit special contracts:

Input						
Use of inputs in mode 1 (parameter 76 = 1)						
EX1	<u>Heating control</u> (for controlling the switch to reduced heating mode on the HP).					
EX2	EX2 DHW control (to force refilling of the DHW tank (forced operation)).					
Use of in	puts in mode 0 (parameter 76 = 0)					
EX1	Load shedding / peak shaving (to prohibit back- ups (and the compressor if parameter 79 = 1)).					
EX2	Peak/Off-peak times (to control the switch to DHW comfort mode on the HP).					
EX1 + EX2	Launch of DHW forced operation.					

- Peak/off-peak rates, day / night rates

In particular, domestic hot water (DHW) at Nominal temperature will be produced during the off-peak hours when electricity is cheaper.

Connect the "energy supplier" contact to input **6** (Rates - EX2) *figure 32*.

- Load shedding or peak shaving

The purpose of load shedding is to reduce the electrical consumption when it is too high compared to the contract with the energy supplier.

Connect the load shedder to input **5 (Load Shedding - EX1)** *figure 32*.

Faults outside the heat pump

All information devices (thermostat, pressure switch, heated floor safety device, etc.) may indicate an external problem and stop the heat pump.

- Connect the external device to input 7 (External errors EX3) figure 32.
- 230 V on input **EX3** = heat pump shutdown (the system displays error *Er 73*).

Energy meter

A signal is used to show the energy distribution for Heating/DHW functions by connecting a compatible energy meter. Depending on the appliance (refer to the meter's instructions manual):

1 If the metering convention is:

0V for heating and 230V for DHW (applicable to the HP pack), connect the meter to terminals 18 (white) and 19 (grey) (*figure 33*).

2 If the metering convention is:

230V for heating and 0V for DHW, connect the meter to terminals 17 (black) and 18 (white) (*figure 34*).



figure 33 - Connection example (HP pack energy meter)



figure 34 - Connection example (energy meter)

5.2 Electrical connections - SELV

The elements described below are Safety Extra-Low Voltage devices (SELV). Comply with the regulations applicable to such devices.



figure 35 - SELV cable bushing

5.2.1 Outdoor sensor

The Outdoor sensor is required for the correct operation of the heat pump.

Place the sensor on the coldest part, generally the northern or north-eastern side. In any case, it must not be exposed to the morning sun. It must be installed so that it is easily accessible but at least 2.5 m from the ground. Avoid sources of heat such as chimneys, the tops of doors or windows, nearby extraction ducts, underneath balconies and porches, that would insulate the sensor from the variations in the temperature of the outside air.

- Connect the outdoor sensor (figure 36).

Comply with the safety distances between SELV and LV (power) cables.

Ensure that all of the electrical cables are housed in the spaces provided (*figure 35*).



figure 36 - Connections to the HP controller (accessories and options)



figure 37 - Outdoor sensor (recommended exposure)

5.2.2 Room thermostat

Dynamic radiator or fan-coil area

If the installation is equipped with fan-coils / dynamic radiators, **do not use a room thermostat.**

Radiator or floor heating area

Consult the assembly instructions on the packaging of the sensor.

The thermostat must be installed in the area requiring control on a very uncluttered wall. It must be installed so as to be easily accessible. Avoid sources of direct heat (chimney, television, cooker, sunlight) and areas exposed to draughts (ventilation, doors).

Draughts due to the building usually cause cold air to enter via the electrical ducts. Seal the electrical ducts if there is a cold draught at the back of the room thermostat.

Connect the room thermostat 1 (*figure 36*). Connect the room thermostat 2 (*figure 36*).

5.2.3 Telephone modem (optional)

Connect the telephone control outlet to the modem terminals (see *figure 36*).

The telephone control is used to switch the mode currently in use:

Use	Current mode		Switch
Heating	PROG	\Leftrightarrow	
Cooling	PROG	\Leftrightarrow	OFF
DHW	PROG	\Leftrightarrow	OFF



figure 38 - Position of the room thermostat

6 Commissioning

6.1 Checks before commissioning

Hydraulic circuit

- Make sure that the installation has been rinsed.
- Check the water flow direction and that all of the valves are open.
- Electrical circuit
- Check that the phase-neutral polarity of the electrical power supply is respected.
- Check that all the equipment is connected to the relevant connection terminals.

6.2 Commissioning

6.2.1 Filling and draining the installation

- Fill the installation.
- Perform a leak test for the whole installation.
- Do not operate the circulating pump while filling. Open all the drain valves in the installation to remove the air contained in the pipes.
- Close the drains and add water until the pressure of the hydraulic circuit reaches 1.5 bar.

6.2.2 First power on

- Close the installation's main circuit breakers.

When first put into service (or in winter), to preheat the compressor, close the main circuit breakers of the installation (outdoor unit power supply) for several hours before the tests.

To guarantee the correct operation of inputs **EX1**, **EX2**, **EX3**: Check that the phase-neutral polarity of the electrical power supply is respected.

When put into service and every time that the main circuit breaker is cut off then reconnected, the outdoor unit requires approximately 3 minutes to start up even if the regulation has demanded heating.

While the regulator is being initialised the display shows all icons.

Note: When starting up the heating function after the HP has been fully shut down and for a heating network temperature not exceeding 17°C, the electrical back-up is automatically activated.

6.2.3 Draining the hydraulic unit

Press and hold the $\bigcirc \mathbb{M}$ button for 5 seconds; the display will show the " \bigcirc " icon.

- Installation with DHW tank
- Set the valve to the intermediary position (see *figure 39*).
- Follow the procedure. See below.
- Installation of heating system only
- **1** Set parameter **"96"** (Appliance test) to **10** (activation of all circulation pumps).
- **2** Open all the drain valves in the installation to remove the air contained in the pipes.
- **3** Close the drains and add water until the pressure of the hydraulic circuit reaches 1.5 bar.
- 4 Set parameter "96" to 0 (no test).
- Precise filling pressure is determined by the manometric head of the installation.
- 5 Check that there are no leaks.



figure 39 - Distribution valve (optional DHW kit)

6.2.4 Setting the parameters

Configure all of the specific settings for the regulation (configuration of the installation in particular): list of settings *page 44*).

6.3 Cleaning the filter valve

Immediately after commissioning, clean the filter of the filter valve (remove waste generated by the installation: seals, oakum, filings, etc.).



6.4 Circulation pump operation

The speed of the heating circulation pump can be adjusted via the user interface (see *"70", page 46*). By default, the pump is set to the maximum speed (speed 4).

Circulation pump errors:

- If the flow rate is too low, error **Er 3** is displayed. The pump is shut down for a few minutes only, before trying again.
- If the problem persists, **Er 131** is displayed. The appliance then becomes locked: press "**OK**" to restart the appliance.

6.5 Floor drying mode

The control can be configured to manage the floor drying function of the floor heating system (parameter "94", page 47).

This mode is used to manually configure the initial constant heating / HP setpoint for each circuit.

The parameter must be set to "**Off**" to deactivate the floor drying mode.



Floor drying mode does not work if the room thermostat is connected.

The room thermostat must be disconnected for this mode to work.

0	OFF	Voyant éteint : Le circulateur ne fonctionne pas, pas d'alimentation électrique.
	🗸 ON	Voyant allumé vert : Le circulateur fonctionne normalement.
	🗸 Stand-by	Voyant clignotant vert : Le circulateur est arrêté par le signal de commande, pas de défaut.
	Auto Test	Voyant clignotant vert/rouge : Erreur de fonctionnement avec redémarrage automatique.
	2 C	Voyant clignotant rouge: Erreur de fonctionnement, contacter votre installateur.

figure 40 - Circulation pump operating signals

7 Controller

7.1 User interface



Ref.	Functions	- Definition of the functions
1	• SELECT	- Browse and select the available uses .
2	• MODE	- Browse and select the mode for the pre-selected use.
3	SettingsScrolling	 Configure the setpoints of the selected function using the and keys. Scroll through the information and parameter lines. Configure the modifiable values (after pressing OK to confirm).
4	Information	- Access the "information" menu (the i icon appears)
	 "ESC" output 	- Exit the menu currently displayed - Cancel a modification being made
5	Configuration	 Access the user level (press and release: the <i>racess is a constant of the installer level (press and hold (for more than 5s): the the installer level (press and hold (for more than 5s): the the isometry is a constant of parameters and hold (for more than 5s): the the isometry is a constant of the isometry isometry is a constant of the isometry isometry isometry is a constant of the isometry i</i>
6	• OK	- Confirm (Configuration, Setpoint for the pre-selected mode)
7	• Display	- Display: see § "Description of the display (user interface).", page 41 - View the settings.

* These parameters (or menus) may not appear. They depend on the appliance's configuration (on the options selected).

• Description of the display (user interface).



Icons	Definitions
٢	Access the User settings
	Use for heating (reference to the circuit concerned Z1 or Z2)
-	Use for DHW
	Use for cooling (reference to the circuit concerned Z1 or Z2)
\bigcirc	Stand-by ⁽¹⁾
\bigcirc	Compressor operation
 ⊧ ≁	Electrical back-up operation (heating or DHW)
PROG	PROG mode: Controlled operation according to the: - programme set in the User interface or the - programme set on the room thermostat
ECO	Constant mode (with reduced temperature setpoint)
兴. _{or}	Constant mode for heating or cooling (with comfort temperature setpoint)
Ē	Absence mode
OFF	The use concerned is in Off mode (area 1 / 2 - DHW)
i	Read information
E.	Access the Installer settings
(1) Frost protection	provided that the electric power supply to the HP

⁽¹⁾ Frost protection provided that the electric power supply to the HP is not switched off.

7.2 Room thermostat (optional)



If the installation is equipped with one or more room thermostats, the timer for each area is exclusively managed on the dedicated thermostat. Refer to the room thermostat instruction manual.

• Description of the display (room thermostat).

	123456 00:00 out 0000 boost 0000 1 2 3 4 5 6 7
lcons	Definitions
	Heating indicator
-T-I	DHW indicator*
켰	Cooling indicator*
	Current configuration
BOOST	Exemption (Heating or DHW*)
Ē	Absence mode
0.0.0	Display: Temperature / Setpoint value / Error codes
OUT	Outdoor indicator temperature
18:30	Time display
123456	Current programming period (4 max.)
1 2 7	Current day (1 = Monday, 7 = Sunday)

7.3 Start temperature calculation

7.3.1 Weather-dependent control

The operation of the heat pump is controlled by the weather-dependent setpoint.

The set temperature for the water in the heating circuit is adjusted according to the outdoor temperature.

If there are thermostatic valves on the installation, these must be fully open.

Manual configuration

During installation, the weather-dependent setpoint must be configured according to the heat emitters and the residence's insulation.

The weather-dependent setpoint curves (*figure 41*) refer to an ambient setpoint of 20°C.

The weather-dependent setpoint slope (parameter **30/50** - see "*Heating setting, circuit 1 (direct)*", page 45) determines the impact of variations in outdoor temperature on the variations in initial heating temperature.

The steeper the slope, the more a slight reduction in the outdoor temperature causes a significant increase in the initial water temperature in the heating circuit. The weather-dependent setpoint offset (parameter **31/51**) modifies the initial temperature of all the curves, without modifying the slope (*figure 42*).

The corrective actions if discomfort is experienced are listed in the table (*figure 43*).

7.3.2 Room influence

When the room influence is activated (parameter **33** for circuit 1 and **53** for circuit 2), the heating circuit water setpoint temperature is adjusted according to the outdoor temperature and the room temperature.

The room temperature's impact is weighted by this parameter, from 1 to 99%.

7.3.3 Room control

When the room influence is set to 100%, the heating circuit water setpoint is calculated only according to the difference between the room setpoint and the room temperature.

This operating mode provides better thermal comfort.







figure 42 - Heating curve displacement (line 31 / 51)

Feel	lings	-+	Corrective actions on the weather-dependent setpoint:		
in warm weather	in cold weather		Slope (line 30 / 50)	Offset (line 31 /51)	
в ок 8	S S OK		No correction	No correction	
Cold 8	Hot	-+		+	
Cold 8	СК В	-	\rightarrow	A	
Cold 8	Cold	-	 No correction 	A	
з ОК 8	Hot	-	\bullet	No correction	
500 OK 8	Cold	-+		No correction	
F Hot 8	Hot	-	No correction		
77 Hot 8	K S	-			
	Cold	-	· _		

figure 43 - Corrective actions in case of discomfort

7.4 Regulation parameters

7.4.1 Overview

Two viewing modes are available: *I* - User. *G* - Installer.

The access levels are specified in the second column of the table with the corresponding icons.

7.4.2 Setting parameters



7.4.3 Recommended settings for the parameters depending on the installation's transmitters

Heating		VLT Radiators / Heating- cooling floor	Low temperature radiators	Classic temperature radiators	Dynamic radiators or fan-coil heaters	
Heating curve	30 (CC1)	0.25 to 0.5	0 5 to 1 25	1.25 to 2	0.4 to 1.1	
slope	50 (CC2)	0.25 10 0.5	0.5 10 1.25	1.25 to 5	0.4 to 1.1	
Curve	31 (CC1)	0	0	0	Α	
off-set	51 (CC2)	U	0	0	4	
Max.	32 (CC1)	50°C (factory satting)	50°C (factory	50°C (factory	EO°C (factory actting)	
initial setpoint	52 (CC2)		setting)	setting)		
Influence of room	33 (CC1)	With room thermostat. The set	tings depend on the acc	curacy of the	0% (room thermostat	
temp.	53 (CC2)	installation).			prohibited)	

Loria 6000 heat pump

7.4.4 List of parameters

No.		Description of parameter	Configuration or display range	Basic setting
Time / I	Date s	etting		
1	۲	Hours / minutes	00:00 23:59	01:00
2	۲	Month / Day	1 - 1 12 - 31	MM-DD
3	۲	Year	2018	YYYY
Installa	tion c	onfiguration		
4	G	Two heating circuits option	1 3	1
		This control enables you to choose one of the 2 p 1 (1 heating circuit); 2 (not used); 3 (2 heating	re-selected installation configurations. circuits with uncoupling bottle).	
5	G	Domestic hot water option	0 (heating only) 1 (heating + DHW)	0
6	G	General cooling authorisation.	0 (not allowed) 1 (allowed)	0
7	G	Heating back-up prohibited (1)	0 (no) 1 (yes)	0
8	G	DHW back-up prohibited	0 (no) 1 (yes)	0
9	G	Software version	0 99.9	-
Absend	ce moo	de		
10	۲	Absence mode temperature setpoint	5 °C 20 °C	13 °C
		Adjustment of the temperature setpoint used durin	ng absence mode.	
Heating	g time	programme ⁽²⁾ , circuit 1 (direct)		
11	۲	Pre-selection (day / week)	1 10	-
		1 = Monday; 2 = Tuesday 7 = Sunday; 8 = Mo 10 = Monday to Sunday (modifications are applied	nday to Friday; 9 = Saturday and Sunday ed to the whole week)	
12	۲	1 st phase of the selected day (start of comfort)	00:00 23:45	06:00
13	٢	1 st phase of the selected day (end of comfort)	00:15 24:00	22:00
14	۲	2 nd phase of the selected day (start of comfort)	00:00 23:45	:
15	۲	2 nd phase of the selected day (end of comfort)	00:15 24:00	:
16	۲	3 rd phase of the selected day (start of comfort)	00:00 23:45	;
17	۲	3 rd phase of the selected day (end of comfort)	00:15 24:00	:
Heating	g time	programme ^{(1) (2)} , circuit 2 (combined)		
18	ľ	Pre-selection (day / week)	1 10	-
		1 = Monday; 2 = Tuesday 7 = Sunday; 8 = Mo 10 = Monday to Sunday (modifications are applied	nday to Friday; 9 = Saturday and Sunday ed to the whole week)	
19	٢	1 st phase of the selected day (start of comfort)	00:00 23:45	06:00
20	٢	1 st phase of the selected day (end of comfort)	00:15 24:00	22:00
(1) The second		· · · · · · · · · · · · · · · · · · ·		

⁽¹⁾ These parameters (or menus) may not appear. They depend on the appliance's configuration (on the options selected). ⁽²⁾ With a room thermostat, these menus are not shown on the user interface. The time programme is only managed using the room thermostat in the area considered.

No.		Description of	parameter		Configu or displ	iration ay range		Basic setting
21	۲	2 nd phase of the	e selected d	ay (start of com	fort) 00:00	23:45		;
22	۲	2 nd phase of the	e selected d	ay (end of comf	ort) 00:15	24:00		:
23	۲	3 rd phase of the	selected da	ay (start of com	fort) 00:00	23:45		:
24	۲	3 rd phase of the	selected da	ay (end of comf	ort) 00:15	24:00		:
IW ti	mer pr	ogramme (1)						
25	۲	Pre-selection (day / week)			1 10			-
		1 = Monday; 2 = 10 = Monday to	= Tuesday Sunday (m	. 7 = Sunday; 8 lodifications are	= Monday to Fri applied to the w	day; 9 = Saturda hole week)	y and Sunday	
26	۲	1 st phase of the	selected da	ay (start of comf	fort) 00:00	23:45		00:00
27	۲	1 st phase of the	selected da	ay (end of comfo	ort) 00:15	24:00		05:00
28	۲	2 nd phase of the	e selected d	ay (start of com	fort) 00:00	23:45		14:30
29	۲	2 nd phase of the	e selected d	ay (end of comf	ort) 00:15	24:00		17:00
eating	g settii	ng, circuit 1 (dir	ect)					
30	G	Heating curve s	slope		0.10 4	.00		0.7
31	G	Heating curve of	displacemer	ıt	-4.5 4.	5°C		0 °C
32	G	Max. initial hea	ting setpoin	t	20 60°	С		50 °C
33	G	Room temperat	ture influenc	е	0 1009	0 100%		
		If the installation temperature's in If no value is er	n is fitted wi nfluence on ntered, only	th a room therm the setting. the weather-de	nostat (area 1): T pendent setpoint	his function enat	oles you to choose the ambier	ıt
34	G	Parameter not	used		0 (not us	sed) 1 (on)		1
35	G	Zone 1 emitter	type		0 (Radia	itor) 1 (Underfl	oor heating)	0
36	G	Accelerated lov	vering		0 (off)	4		0 °C / h
		This function er The time the he	nables you t eating is stor	o force the heat	ting to stop when ed according to t	the temperature	e setpoint is lowered. d the difference in setpoint.	
				Setpoint to	emperature diffe	rence (°C)	1	
				1	2	3	1	
			0,5	2hrs	4hrs	6hrs		
			1	1hr	2hrs	3hrs		
		Parameter	1,5	40 mn	1hr20	2hrs	Heating stoppage time	•
			/					
			3	20 mn	40 mn	1hr		
		NB: The func	tion is not	used if a room	accessorv is co	onnected.	1	
					,			
37	Ð	Zone 1 mid-sea	ason econor	ny	0 (off)	1 (on)		0

 ⁽¹⁾ These parameters (or menus) may not appear. They depend on the appliance's configuration (on the options selected).
 ⁽²⁾ With a room thermostat, these menus are not shown on the user interface. The time programme is only managed using the room thermostat in the area considered.

	Description of parameter	Configuration or display range	Basic setting
setti	ng ⁽¹⁾ , circuit 1 (direct)		
₿	Cooling authorisation (circuit 1) (1)	0 (no) 1 (yes)	0
G	Cooling curve slope	0.10 4.00	0.7
G	Cooling curve displacement	-4.5 4.5°C	0 °C
G	Min. initial cooling setpoint	5 30 °C	10 °C
settii	ng ⁽¹⁾ , circuit 2 (combined)		
G	Heating curve slope	0.10 4.00	0.7
G	Heating curve displacement	-4.54,5 °C	0 °C
G	Max. initial heating setpoint	20 60 °C	45 °C
G	Room temperature influence	0 100%	0%
	If the installation is fitted with a room thermostatemperature's influence on the setting. If no value is entered, only the weather-dependence	at (area 2): This function enables you to choose the dent setpoint is configured.	ambient
G	Parameter not used	0 (not used) 1 (on)	1
G	Zone 2 emitter type	0 (Radiator) 1 (Underfloor heating)	0
G	Zone 2 mid-season economy	0 (off) 1 (on)	0
	The heating request stops when the exterior te	mperature is higher than the setpoint +1°C	
setti	ng ⁽¹⁾ , circuit 2 (combined)		
G	Cooling authorisation (circuit 2) (1)	0 (no) 1 (yes)	0
G	Cooling curve slope	0.1 4.00	0.7
G	Cooling curve displacement	-4.54,5 °C	0
G	Min. initial cooling setpoint	5 30 °C	10 °C
ion p	ump		
G	Pump speed	1 4	4
mp			
G	Heating standby switchover authorisation	0 (manual) 1 (automatic)	1
٢	Automatic change in state according to the outdoor temperature (heating <> stand by).	15 30 °C	18 °C
	When the average of the outdoor temperatures measure).	reaches 18°C, the regulator switches off the heati	ng (as an econom
4	Lesienelle function (1)	0(-f) $1(-r)$	
		Setting ⁽¹⁾ , circuit 1 (direct) Image: Cooling authorisation (circuit 1) ⁽¹⁾ Image: Cooling curve slope Image: Cooling curve displacement Image: Cooling curve displacement <td>Description of parameter Configuration or display range setting ", circuit 1 (direct)</td>	Description of parameter Configuration or display range setting ", circuit 1 (direct)

⁽¹⁾ These parameters (or menus) may not appear. They depend on the appliance's configuration (on the options selected). ⁽²⁾ With a room thermostat, these menus are not shown on the user interface. The time programme is only managed using the room thermostat in the area considered.

No.		Descriptio	on of parameter		Configuration or display range		Basic setting	
74	۲	Correction	of outdoor tempera	ture sensor	- 5 5 °C		-	
75	5	Behaviour an externa	of the appliance wh I error - EX3 (see ta	nen suffering from able <i>page 50</i>).	1 (appliance locked) 2 (Area 1 off) 3 (Area 2 off)		1	
76	G	Rates mod	le		0 (Load shedding - Pea rate) 1 (DHW boost / Eco he	ak shaving / Reduced eating circuit)	0	
		Peak shavi shedding)	ing (or load contract	Back-up(s) when sh Back-up(s) + comp Heating operation a	<u>ut down</u> => No. 76 set t essor when shut down ccording to reduced ter	to 0 and No. 79 set to => No. 76 set to 0 and <u>mperature setpoint</u> =>	0 I No. 79 set to 1 No. 76 set to 1	
		Peak / off-p contract	peak times	<u>DHW operation (co</u> DHW boost (DHW f	nfort temperature setpo orced operation at time	<u>pint)</u> => No. 76 set to 0 <u>e of switching)</u> => No. 7	6 set to 1	
77	ß	0 (Load shedding or peak shaving if 0V, N Direction of action input 5 (Load Shedding - EX1) 230V) 1 (Load shedding or peak shaving if 230V				eak shaving if 0V, Norr eak shaving if 230V, N	mal operation if ormal operation if 0V)	
78	G	Direction of action input 6 (Rates - EX2) 0 (off-peak if 0V, peak if 230V) 1 (off-peak if 230V, peak if 0V)				if 230V) ak if 0V)		
79	G	Compresso	Compressor load shedding forbidden 0 (no) 1 (yes)			0		
		Only used	with peak shaving (or load shedding) co	ntract, when paramete	r 76 is set to 0.		
80	G	EU referen	nce power		0 10,0 kW		-	
		Adjust acco	ording to the appliar	ice's power:				
			Loria 6004	Loria 6006	Loria 6008	Loria 6010		
			WOYA060LFC / WOYA060LFCA	WOYA060LFC / WOYA060LFCA	WOYA080LFC / WOYA080LFCA	WOYA 100 LDT / WOYA100LFTA		
		kW		1.8	2.3	3.1		
81	G	DHW elect	trical back-up powe	r (1)	0 10,0 kW		-	
		Adjust acco	ording to the DHW t	ank's power.				
94	G	Floor dryin	g		0 3		0	
		0 = Off; 1 =	= Area 1; 2 = Area 2	; 3 = Area 1 + Area 2				
		This param	eter is used to manu	ally configure the initi	al constant heating setp	oint for each circuit.		
		• The para	meter must be set	to "Off" to deactive	ate the floor drying m	ode.		
95	۲	DHW boos	st (1)		0 (off) 1 (on)		0	
96	G	Appliance	test		0 10			
		This param operating a automatica	This parameter is used to test the components connected to the controller. It is used to check that the relays are operating and that the wiring is correct (for this, check that each appliance is operating on the installation). The test automatically stops after 20 minutes.					
		☞ Durin when	g the tests, the H the component o	P safety devices a operation is validation	re deactivated. An or ted (reset the parame	ngoing test must be eter to 0).	stopped in all cases	
		 0 = No test up test + in position); 5 = Mixing va 8 = Circula 	t; 1 = Compressor to nternal circulation po 5 = DHW electrical to alve (open position tion pump test for c	est (the HP starts at ump test; 3 = Distribu back-up test; 6 = Mixi - direct circulation) a ircuit 1; 9 = Circulation	50% as well as all circu tion valve test (heating ng valve (closed position nd circulation pump test on pump test for circuit	lation pumps); 2 = He position); 4 = Distribu on) and circulation pur t for 2 nd circuit; 2; 10 = Operation of a	ating electrical back- tion valve test (DHW np test for 2 nd circuit; 7 Il circulation pumps.	
97	۲	Assist mod	le		0 (Assist mode off) 1 (Assist mode on)		0	

⁽¹⁾ These parameters (or menus) may not appear. They depend on the appliance's configuration (on the options selected). ⁽²⁾ With a room thermostat, these menus are not shown on the user interface. The time programme is only managed using the room thermostat in the area considered.

Information and troubleshooting 8

8.1 Displaying information The i^{i} button calls up various information.

Depending on the appliance type, the configuration and the state of operation, certain information lines may not be available.

List of information

i	No Name	Value
1	Time.	hh:mm
2	Outdoor temperature.	°C
3	Circuit 1: Initial temperature.	°C
4	Circuit 1: Initial setpoint.	°C
5	Return temperature.	°C
6	Flow measurement.	l/min
7	Compressor modulation level.	%
8	Heating back-up status.	0 = off 1 = on
9	Circuit 2: Initial temperature.	°C
10	Circuit 2: Initial setpoint.	°C
11	DHW temperature.	°C
12	DHW setpoint.	°C
13	HP status.	
14	Heating circuit 1 status.	see details § " -
15	Heating circuit 2 status.	Status list"
16	DHW circuit status.	
17	DHW back-up status.	0 = off 1 = on
18	Outdoor unit error code.	(see table page 51).
Ene	rgy consumption	Value
30	Heat Energy consumed this month	kWh
31	Heat Energy consumed last month	kWh
32	Heat Energy consumed this year	MWh
33	Heat Energy consumed last year	MWh
40	Cool Energy consumed this month	kWh
41	Cool Energy consumed last month	kWh
42	Cool Energy consumed this year	MWh
43	Cool Energy consumed last year	MWh
50	DHW - Energy consumed this month	kWh
51	DHW - Energy consumed last month	kWh
52	DHW - Energy consumed this year	MWh
53	DHW - Energy consumed last year	MWh

Status list

i No.	Value	HP status
	0	Pending.
	1	Heating.
13	2	Cooling.
	3	Error.
	4	Assist mode.
	5	Locked.
	6	Defrost activated.
	7	Test mode.
i No.	Value	Heating circuit 1 and 2 status
	0	Pending.
	1	Comfort heating mode.
	2	Reduced heating mode.
	3	Comfort cooling mode.
14	4	Reduced cooling mode.
15 15	5	Absence mode.
	6	Controlled by the room thermostat.
	7	Frost protection activated.
	8	Floor drying mode.
	9	Rate input activated.
i No.	Value	DHW status
	0	Pending.
	1	Comfort mode, charge activated.
16	2	Reduced mode, charge activated
10	3	Legionella charge.
	4	Frost protection activated.
	5	Forced operation. (boost)

8.2 Hydraulic unit errors

The faults or breakdowns of the hydraulic unit are reported on the display unit of the user interface. The display shows the *"ERXXX"* error code. A minor error does not result in switching the appliance to safety mode. A major error results in switching the appliance to safety mode. After solving the problem, press or (reset and cancel the error message).

ଙ Visib	le faults o	on the digital display.		
Error	codes			
Minor error	Major error	Description	Switched to safety mode	Probable causes
3	-		-	Circulation nump around acttings too
-	131	Hydraulic flow rate too low.	(Appliance shutdown if the error 3 occurs 3 times in 1 hour)	low. Clogged filter valve.
5	-	Initial temperature (T5) or return temperature (T6) < 2°C	-	Frost protection function defective. Back-up disconnected.
6	-	Communication error between the interface board and the HP regulator board.	-	Check the wiring.
19	-	Test mode activated.	-	-
35	-	HP outgoing flow sensor error (T5).	-	Short circuit, sensor disconnected or cut off. Defective sensor. Other error.
36		HP return flow sensor error (T6).	-	Short circuit, sensor disconnected or cut off. Defective sensor. Other error.
-	132	Initial temperature > 70 °C (T5)	-	
46	-	Circuit 2 sensor error (T12)	-	Short circuit, sensor disconnected or cut off. Defective sensor. Other error.
48	-	Outdoor temperature sensor error (T7)	-	Short circuit, sensor disconnected or cut off. Defective sensor. Other error.
47	-	DHW tank sensor error (T8)	-	Short circuit, sensor disconnected or cut off. Defective sensor. Other error.
-	148	Legionella cycle error	This error appears if 3 consecutive tests fail.	DHW back-up disconnected.
52	-	Frost detected on the return	-	
-	180	circuit when defrosting the outdoor unit (temperature < 2 °C).	Appliance shutdown if the error 52 occurs 3 times in 1 hour.	Circulating water volume too low
53	-	Frost detected on the outgoing	-	(see table §1.3, page 5).
-	181	circuit when defrosting the outdoor unit (temperature < 3 °C).	Appliance shutdown if the error 53 occurs 3 times in 1 hour.	
55	-	Frost protection of the HP circuit activated (with electrical back-up)	-	-
56	-	Frost protection of the DHW tank activated (with electrical back-up)	-	-
62	-	Load shedding - peak shaving or rate input activated	-	-
66	-	Outdoor unit error (external cause)	-	See "8.3 Outdoor unit errors", page 51
67	-			Too much draw-off during the same
-	195	DHW cycle too long (> 6 hours).	Appliance shutdown if the error 67 occurs 3 consecutive times.	cycle. DHW back-up disconnected.

C Always check that the electric power supply is switched off before maintaining the boiler.

☞ Visib	☞ Visible faults on the digital display.						
Error	codes						
Minor error	Major error	Description	Switc	hed to safety mode	Probable causes		
68	-	Room temperature in area 1 missing when the "room T° influence" function (No. 33) is activated.		-	Parameter 33 used without room unit. Room unit disconnected or absent.		
69	-	Room temperature in area 2 missing when the "room T° influence" function (No. 53) is activated.	-		Parameter 53 used without room unit. Room unit disconnected or absent.		
70	-	Assist mode activated.		-	-		
71	-	Circuit temperature 2 > 55 °C		-	Defective mixing valve.		
73	-	External error linked to input EX3.	Parameter 75 set to	 HP locked Area 1 shut down Area 2 shut down 	Outdoor component error.		
76	-	Low hydraulic flow rate.		-	Circulation pump speed settings too low. Clogged filter valve.		

8.3 Outdoor unit errors

In the event of an error occurring within the outdoor unit, the user interface displays the "Er 66" error code. View the information menu i (: Information " i No. 18" specifies the error code for the outdoor unit " i xx" (list provided below).

Outdoor	Interfac	e board	Outdoor unit board	Error contento
code	LED 2 (green)	LED 1 (red)	LED	Error contents
0			Off	Communication error between the interface board and the outdoor unit: transfer error (Serial reverse).
1	I FIGSI	I FIASII	1 Flash	Communication error between the interface board and the outdoor unit: transfer error (Serial forward).
2	4 Flashes	2 Flashes	22 Flashes	Hydraulic unit exchanger temperature sensor error.
3	6 Flashes	3 Flashes	18 Flashes	Inverter error.
4	6 Flashes	4 Flashes	19 Flashes	Active filter error / PFC error
5	7 Flashes	1 Flash	2 Flashes	Discharge temperature sensor error.
6	7 Flashes	2 Flashes	8 Flashes	Compressor temperature sensor error.
7	7 Flashes 3 Flashes		5 Flashes	Exchanger temperature sensor (centre) error.
8			4 Flashes	Exchanger temperature sensor (output) error.
9	7 Flashes	4 Flashes	7 Flashes	Outdoor temperature sensor error.
10	7 Flashes 7 Flashes		9 Flashes	Radiator temperature sensor (inverter) error.
11			10 Flashes	Radiator temperature sensor (P.F.C.) error.
12	7 Flashes	8 Flashes	6 Flashes	Pressure regulator temperature sensor error.
13	8 Flashes	4 Flashes	-	Current current error.
14	8 Flashes	6 Flashes	3 Flashes	Pressure sensor error / pressure switch error.
15	9 Flashes	4 Flashes	13 Flashes	Current sensor error (permanent shutdown).
16	9 Flashes	5 Flashes	14 Flashes	Detection error for the position of the compressor rotor (permanent shutdown).
			15 Flashes	Compressor start-up error (permanent shutdown).
17	9 Elashas	7 Elashas	16 Flashes	Outdoor unit fan motor 1 error.
17	5 Flashes	7 Flashes	17 Flashes	Outdoor unit fan motor 2 error.
18	10 Flashes	1 Flash	11 Flashes	Discharge temperature protection (permanent shutdown).
19	10 Flashes	3 Flashes	12 Flashes	Compressor temperature protection (permanent shutdown).
20	10 Flashes	5 Flashes	20 Flashes	Abnormal low pressure.
21	Depending or	n the outdoor u	nit error	Error originating from the outdoor unit.
22	3 Flashes	2 Flashes	-	Communication error between the interface board and the HP regulator board.

C Always check that the electric power supply is switched off before maintaining the boiler.

8.4 Safety thermostat

When the temperature in the electrical back-up exceeds 90°C, the HP is stopped by its overheating safety device. Always check that the electric power supply is switched off before works.

☞ ⚠️ Stored energy: after disconnecting the power supplies, <u>wait 1 minute</u> before accessing the internal parts of the equipment.

Remove the expansion vessel (*figure 46*) and reset when the water temperature has returned to normal.



figure 44 - Reset button (overheating safety device)

9 Maintaining the installation

- Ensure that <u>all electrical power supplies</u> have been cut off before starting work.
- ☞ ▲ Stored energy: after disconnecting the power supplies, wait 1 minute before accessing the internal parts of the equipment.

9.1 Hydraulic checks

Regular maintenance is required to protect the HP.

Note: Protection via the detection of the minimum flow rate stops the HP under poor operating conditions (clogged filter, water shortage, etc.).

Depending on the frequency described below, clean the filter valve (where necessary the sediment trap) and check the pressure.

- Immediately after commissioning (remove waste generated by the installation: seals, oakum, filings, etc.),
- In the first two months after commissioning and depending on the type of installation,
- Then during each maintenance operation (remove particulate matter and sediment contained in the heating water).

9.1.1 Cleaning the filter valve

- Close the valve.
- Unscrew the cap.
- Remove the clip using pliers.
- Clean the filter.

9.1.2 Cleaning the sediment trap

Refer to the manufacturer's instructions.

9.1.3 Annual inspection

Check the heat output: assessment with the temperature deviation (outgoing - return) and flow rate.

Warning : If frequent refills are required it is essential that you look for any leaks.

If you need to fill up and reset the pressure, check the type of fluid originally used.

Recommended filling pressure: between 1 and 2 bar (the exact filling pressure is determined according to the installation's manometric head).

Every year.

- Check the expansion vessel pressure (pre-inflation of 1 bar) and the correct operation of the safety valve.

If the installation is fitted with a DHW tank:

- Verify the safety unit on the cold water supply inlet.
- Run it according to the manufacturer's instructions.
- Check the disconnector.



figure 45 - Filter valve: filter removal

9.2 Checking the outdoor unit

- Remove any dust from the exchanger making sure you do not damage the blades.
- Correct the blades using a comb.
- Check that there is nothing hindering the air flow.
- Check the fan.
- Check that the condensate discharge is not blocked.

Checking the refrigeration circuit

- Check that there are no leaks (connectors, valves, etc.).

9.3 Electrical checks

- Check connections and tighten where necessary.
- Check the condition of the cabling and plates.

10 Maintenance

- Ensure that <u>all electrical power supplies</u> have been cut off before starting work.



figure 46 - Removable expansion vessel

10.1 Draining the hydraulic unit

- Close the valves (pressure gauge and filter valves).
- Open the bleed tap.
- Open the installation air bleeder.

10.2 Replacing fuses

The fuses are located on the printed circuit boards and the supply bundle (see § *11.2, page 58*).

- ☞ Fuse properties:
 - T3.15AH250V, 5x20 mm, IEC 60127-1,
 - T6.3AH250V, 5x20 mm, IEC 60127-1.



figure 47 - Bleed tap

11 Electrical wiring diagrams

11.1 Electrical wiring (outdoor unit)

Electrical connections on the outdoor unit: see § 5.1.5, page 32.



figure 48 - Electrical wiring of the outdoor unit for Loria 6004 & 6006 models







figure 50 - Electrical wiring of the outdoor unit for Loria 6010 model



11.2 Electrical wiring (hydraulic unit - excluding connections made by the installer)

Electrical connections on the hydraulic unit: see § 5.1.6, page 33





12 Quick-start procedure

Before switching on the hydraulic unit :

- Check the electrical cabling.
- Check that the refrigeration circuit is filled with gas.
- Check the hydraulic circuit's pressure (1 to 2 bars), check that the heat pump is drained, along with the rest of the installation.

12.1 Commissioning check-list

12.1.1 Before start-up

Visual inspections

Outdoor unit (see section "2.4 Installing the outdoor unit", page 14).	OK	Non-compliant	
Position and attachments, condensate evacuation.			
Compliance with distances from obstacles.			

Hydraulic checks

Hydraulic unit (see section "4 Hydraulic connections", page 24).	OK	Non-compliant	Value
Connections of pipes, valves and pumps (heating circuit, DHW). Filter valve, pressure gauge valve, sediment trap (optional).			
Comply with the minimum circulating water volume, see table, § <i>1.3, page 5</i> . Correct piping diameter. (expansion vessel of adequate capacity).			
No leaks.			
Primary and gas release network pressure.			

Refrigeration connections and checks

(see section "3 Refrigerant connection and filling the installation with gas", page 17).	OK	Non-compliant	
Refrigerant circuit check (plugged, no dust or moisture)			
Connections between units (pipe length, flare tightening torque).			
HP pressure gauge installation and vacuo on fluid line (small tube).			
Pump down mandatory.			
Leak test with nitrogen (~ 10 bar).			
Opening of refrigeration valves to outdoor unit.			
Filling of the hydraulic unit and pipes with refrigerant.			

Electrical checks

Outdoor unit (see section "5.1.5 Electrical connections on the outdoor unit side", page 32).		Non-compliant	Value
230 V mains power supply			
Protection by calibrated circuit breaker.			
Cable section.			
Earth connection.			

Hydraulic unit (see section <i>"5.1.6 Electrical connections on the hydraulic unit side", page 33</i>).	OK	Non-compliant	
Connection with outdoor unit (L, N, Earth).			
Sensor connections (positioning and connections).			
Connection of distribution valves (DHW) and circulation pump.			
Power supply and protection of electrical back-up.			

12.1.2 Start-up

• Quick start-up

(see section "6.2 Commissioning", page 38) & § "List of parameters", page 44).	OK	Non-compliant	
Push in the installation's circuit breakers (outdoor unit power supply) <u>2 hours before the tests</u> => Compressor preheating.			
Operation of the circulation pump.			
The outdoor unit starts after 3 min.			
Configure the hydraulic circuit (parameter 4 - Two heating circuits option 1 or 3).			
Configure the Time, Date and Heating Circuit, hourly programmes if different from the default values.			
Set the heating slope HC1/HC2 ⁽¹⁾ (30 / 50). Slope of the cooling curve ⁽¹⁾ HC1/HC2 (41 / 42).			
Set the max. initial setpoint HC1/HC2 ⁽¹⁾ (32 / 40). Min. initial cooling setpoint ⁽¹⁾ HC1/HC2 (43 / 44).			

Outdoor unit checks

	OK	Non-compliant	Value
Operation of the fan(s), compressor.			
Current measurement.			
After a few minutes, measure the difference in air T°.			
Condensation and evaporation pressure / temperature check.			

Hydraulic unit checks

	OK	Non-compliant	Value
After 15 minutes of operation.			
Difference in primary water T°.			
Operation of heating, mixing valve, electrical back-up,			

Regulation system

(see section "7 Controller", page 40).	OK	Non-compliant	
Settings, manipulations, checks.			
Set the scheduled periods for heating HC1/HC2 $^{(1)}$ (11 to 17 $^{(2)}$ / 18 to 24 $^{(2)}$).			
Set the scheduled periods for DHW heating ⁽¹⁾ (25 to 29 ⁽²⁾).			
Set the heating circuit setpoints if different to the default values.			
Setpoint display.			
Usage explanations.			

The heat pump is ready for operation!

⁽¹⁾ These parameters (or menus) may not appear. They depend on the appliance's configuration (on the options selected). ⁽²⁾ With a room thermostat, these menus are not shown on the user interface. The time programme is only managed using the room thermostat in the area considered.

12.2 Settings sheet

Parameter	Name	Settings							
Preliminary settings									
1	hour / minutes								
2	Month - Day								
3	Year								
4	Two heating circuits option								
5	Domestic hot water option (1)								
6	general cooling authorisation								
7	Heating back-up prohibited								
8	DHW back-up prohibited								
35 - 55	Type of emitter								
36	Zone 1 accelerated lowering (only if no room thermostat)								
37 - 57	Mid-season economy								
Heating circ	cuit (HC1 / HC2 ⁽¹⁾)								
30 - 50	weather-dependent setpoint slope								
31 - 51	heating curve displacement								
32 - 52	max. initial setpoint								
33 - 53	room T° influence								
11 => 17 & 18 => 23	time programmes (circuit 1) & (circuit 2)								
Cooling circuit ⁽¹⁾ (HC1 / HC2 ⁽¹⁾)									
40 - 60	cooling authorisation								
41 - 61	weather-dependent setpoint slope								
42 - 62	heating curve displacement								
43 - 63	min. initial value								
Circulation	pump								
70	circulation pump speed								

Parameter	Name	Settings						
Domestic hot water (if DHW kit (1))								
73	Legionella cycle							
95	DHW boost							
25 => 29	time programmes							
Energy cou	nting							
80	EU reference power (see <i>page 47</i>)							
81	DHW electrical back-up power (1)							
Miscellaneo	ous							
10	Absence mode setpoint							
72	switch between winter/summer							
74	correct outdoor temperature sensor							
75	behaviour of the appliance when suffering from an external error							
76	rates mode							
77	direction of action input 5 (Load shedding - EX1)							
78	direction of action input 6 (Rates - EX2)							
79	Compressor load shedding forbidden							
94	floor drying							
96	relay test							
97	assist mode							
Errors (see page 49)								
Outdoor unit errors (see page 51)								

⁽¹⁾ These parameters (or menus) may not appear. They depend on the appliance's configuration (on the options selected). ⁽²⁾ With a room thermostat, these menus are not shown on the user interface. The time programme is only managed using the room thermostat in the area considered.

12.3 Start-up data sheet

Worksite					Installer					
	Serial No	rial No			ſ		Serial No	, [
Outdoor unit	Model			Hydraulic unit		it	Model			
	model						model			
Type of refrigerant					Refrigerant ch	narge				kg
Checks					Voltages and	currents	s in operat	tion on the outdo	or unit	
Compliance with position	oning distan	ces			L/N		V			
Correct condensate dis	charge									
Electric connections / c	onnections	ightened			L/T		V			
No GAS leaks (unit ID No.:)								
Correct installation of rem)	efrigerant co	nnection (length			N/T		V			
Reading in HOT opera	ition		r	ļ						
Compressor discharge	temperature)	°C		Icomp		A			
Fluid line T°			°C	}					1	
Condensation T°	HP =	bar	°C	{	Sub-cooling					°C
Tank water output T°			°C	ì	Condensation	ΔT°				°C
Tank water inlet T°			°C	1	Secondary ∆T	•				°C
Evaporation T°	BP =	bar	°C	}					1	
Aspiration T°			°C	ì	Overheating		°C			
Battery air inlet T°	Battery air inlet T°			ì	Evaporation Δ		°C			
Battery air output T°			°C	1	Battery ΔT°					°C
Hydraulic network on	hydraulic u	init	ľ	1	1					
	Underf	loor heating						_		
Secondary network	LT radi	ators			Circulation pu	mp brand	ł	Туре		
	Fan-co	oil heaters								
Domestic hot water; tar	ik type									
Secondary network wat	er volume e	stimate		L						
Options & accessorie	s:		i	1	1					
Power supply for electri	cal back-up				Room thermo	stat				
Location of room senso	r correct									
dual-circuit kit										
DHW kit										
Cooling kit										
					Details					
Control settings										
Type of configuration										
Key parameters					1					

13 Instructions for the user

Explain to the user how the installation operates, in particular the functions of the room thermostat and the programmes accessible via the user interface.

Emphasise that a heated floor has significant inertia and that therefore any adjustments must be made progressively.

Also explain to the user how to check the filling of the heating circuit.

End of life of the device

The apparatus must be dismantled and recycled by a specialised service provider.

The apparatus must never be disposed of with household waste, large objects or in a landfill.

When the apparatus reaches its end of life, please contact you installer or the local representative in order to proceed with the dismantling and recycling of this apparatus.

14 ERP performance values

14.1 ERP definition

"ERP" includes two European directives that are part of the programme for the global reduction of greenhouse gas emissions:

- The eco-design directive sets efficiency thresholds and prohibits the sale of any product with an efficiency lower than the set thresholds.

- According to the labelling directive, energetic efficiency shall be displayed to encourage end users to purchase energy-efficient products.

14.2 ERP Specifications

Trade name / Product name: at	atlantic /		Loria 6004		Loria 6006		Loria 6008		Loria	6010
Reference			522911 522912			912	522	913	522914	
Heating ranges			35°C	55°C	35°C	55°C	35°C	55°C	35°C	55°C
Air/water heat pump						Y	es			
Equipped with a supplementary heater						Y	es			
Average climate - Space heating characteristics										
Energy class Product ^(a)	-	-	A++	A++	A++	A++	A++	A++	A++	A++
Energy class Package	-	-	A+++	A++	A+++	A++	A++	A++	A++	A++
Rated heat output ⁽²⁾	P _{rated}	kW	4	4	6	5	7	6	9	7
Seasonal heating energy efficiency	η	%	181	127	186	128	166	124	154	116
Seasonal efficiency for package with outdoor temperature sensor $\ensuremath{^{(1)}}$	$\eta_{\rm s}$	%	183	129	188	130	168	126	156	118
Seasonal efficiency with room unit (1)	η	%	185	131	190	132	170	128	158	120
Annual energy consumption	Q _{he}	kWh	1884	2708	2588	2933	3226	4197	4481	5256
Colder climate - Space heating characteristics										
Rated heat output ⁽²⁾	P _{rated}	kW								
Seasonal heating energy efficiency	η _s	%]			Ν	IA			
Annual energy consumption	Q_{he}	kWh								
Warmer climate - Space heating characteristics										
Rated heat output ⁽²⁾	P _{rated}	kW	5	5	6	6	7	7	12	8
Seasonal heating energy efficiency	η	%	221	160	242	153	211	154	201	130
Annual energy consumption	Q_{he}	kWh	1270	1793	1201	1936	1866	2349	3040	2990
Acoustic values										
Sound power level of hydraulic unit	L _{WA}	dBa	4	4	4	4	4	4	44	
Sound power level of outdoor unit	L _{wa}	dBa	6	2	6	2	6	9	6	.8
Declared capacity for heating for part load at inde	oor tempera	ature 20°C	and outo	loor temp	perature 7	īj				
Tj = -7°C	Pdh	kW	3.7	3.8	5.2	4.1	5.8	5.6	7.5	6.6
Tj = +2°C	Pdh	kW	2.4	2.5	3.5	2.7	3.7	3.4	4.6	4.0
Tj = +7°C	Pdh	kW	2.0	1.4	1.9	1.8	2.5	2.0	3.2	3.2
Tj = +12°C	Pdh	kW	2.3	2.1	2.4	2.1	2.1	2.0	3.8	3.5
Tj = bivalent temperature	Pdh	kW	3.7	3.8	5.2	4.1	5.8	5.6	7.5	6.6
Tj = operation limit temperature	Pdh	kW	3.4	3.2	4.8	3.9	6.0	4.7	6.9	6.1
Bivalent temperature	T _{biv}	°C	-7	-7	-7	-7	-7	-7	-7	-7
Degradation coefficient (3) (3)	Cdh	-	0.9	0.9	0.9	0.9	0.9	0.9	0.9	0.9
Declared coefficients of performance for part load	d at indoor	temperatui	re 20°C a	and outdo	or tempe	rature Tj				
Tj = -7°C	COP _d	-	2.96	1.95	2.90	1.94	2.56	1.78	2.40	1.80
Tj = +2°C	COP _d	-	4.48	3.21	4.64	3.23	4.20	3.22	3.90	2.80
Tj = +7°C	COP _d	-	6.37	4.41	6.13	4.40	5.69	4.20	5.30	4.40
Tj = +12°C	COP _d	-	8.69	6.50	9.26	6.46	7.20	5.90	7.30	4.90
Tj = bivalent temperature	COP _d	-	2.96	2.00	2.90	1.94	2.56	1.83	2.40	1.80
Tj = operation limit temperature	COP _d	-	2.65	1.62	2.77	1.78	2.37	1.54	2.20	1.60
For air-to-water heat pumps: temperature operating limit	TOL	°C	-10	-10	-10	-10	-10	-10	-10	-10
Water temperature operating limit	WTOL	°C	55	55	55	55	55	55	55	55
Supplementary heater										

Trade name / Product name:	ame: atlantic /		Loria	6004	Loria 6006		Loria 6008		Loria 6010			
Reference			522	911	522912		2 522913		522	914		
Heating ranges			35°C	55°C	35°C	55°C	35°C	55°C	35°C	55°C		
Rated heat output ⁽²⁾	P_{sup}	kW	0.8	1.1	1.1	0.7	0.6	1.8	1.6	1.3		
Type of energy input	-	-				Elec	tricity					
Power consumption in modes other than active	e mode											
Off mode		kW	0.0	009	0.0	009	0.009		0.009 0.007			
Thermostat-off mode	P _{TO}	kW	0.0)14	0.0	014 0.0)15	0.0)54		
Standby mode	P _{SB}	kW	0.0	009	0.0	0.009		0.009		009	0.0	07
Crankcase heater mode	Р _{ск}	kW	0 0		0 0		C	()			
Other properties												
Capacity control	-	-	Inverter									
For air-to-water heat pumps, rated air flow rate, outdoors	-	m³/h	20	70	23	40	36	00	62	00		

(a) The energy class is that of the product. The energy class scale for products is limited to class A++ until 2019.

(1) The detailed calculations are available on the package sheet. The room appliance refers to: the sensors, room thermostats and offset controllers included or not included in the kits.

(2) For room heating devices implementing heat pumps and combined heating devices implementing heat pumps, the rated heat output P_{rated} is equal to the nominal heating load P_{designh} and the rated heat output of a supplementary heater P_{sup} is equal to the supplementary heating capacity sup(Tj).

(3) If the Cdh is not determined by measurements, the default degradation coefficient is Cdh = 0.9.

14.3 Package sheet

Outdoor sensor included in the combined package				
Controller class	II			
Contribution to seasonal efficiency	2%			

Modulating room thermostat references (outdoor sensor included in the package)	076310	(Room thermostat UA55)		
Controller class	VI			
Contribution to seasonal efficiency	4%			

Range 35°C

G	F	E	D	c	в	A	A+	A++	A+++
< 55%	≥55%	≥ 59%	≥61%	≥100%	≥107%	≥ 115%	≥123%	≥150%	≥ 175%

Product name	Loria 6004		Loria 6006		Loria 6008		Loria 6010	
Reference	522911		522912		522913		522914	
Seasonal space heating energy efficiency of heat pump	181%		186%		166%		154%	
Type of temperature control :								
- Outdoor sensor (included in the package)	class II	-						
 Modulating room thermostat (outdoor sensor included in the package) 	-	class VI						
Bonus	2%	4%	2%	4%	2%	4%	2%	4%
Seasonal space heating energy efficiency of package under average climates	183%	185%	188%	190%	168%	170%	156%	158%
Package energy class	A+++	A+++	A+++	A+++	A+++	A+++	A++	A++
Seasonal space heating energy efficiency of package under warmer climates	238%	240%	236%	238%	234%	236%	203%	205%
Seasonal space heating energy efficiency of package under colder climates				N	A			

The energy efficiency of the combined product described herein may not correspond to its actual energy efficiency once installed in a building, as this efficiency is influenced by other factors such as heat loss in the distribution system and the dimensioning of the products in relation to the size and characteristics of the building.

☞ Range 55°C



Product name		Loria 6004		Loria 6006		Loria 6008		Loria 6010	
Reference	522911		522912		522913		522914		
Seasonal space heating energy efficiency of heat pump	12	7%	12	8%	12	4%	114	4%	
Type of temperature control :									
- Outdoor sensor (included in the package)	class II	-							
- Modulating room thermostat (outdoor sensor included in the package)	-	class VI							
Bonus	2%	4%	2%	4%	2%	4%	2%	4%	
Seasonal space heating energy efficiency of package under average climates	129%	131%	130%	132%	126%	128%	116%	118%	
Package energy class	A++	A++	A++	A++	A++	A++	A+	A+	
Seasonal space heating energy efficiency of package under warmer climates	157%	159%	155%	157%	163%	165%	132%	134%	
Seasonal space heating energy efficiency of package under colder climates				N	IA				

The energy efficiency of the combined product described herein may not correspond to its actual energy efficiency once installed in a building, as this efficiency is influenced by other factors such as heat loss in the distribution system and the dimensioning of the products in relation to the size and characteristics of the building.



This appliance conforms to:

- the low voltage directive 2014/35/UE, under standard EN 60335-1, EN 60335-2-40, EN 60529 and EN 60529/A2 (IP),
- the electromagnetic compatibility directive 2014/30/UE,
- the machinery directive 2006/42/EC,
 - the directive for pressurised equipment 2014/68/UE,
 - the eco-design directive 2009/125/EC,
 - the energy labelling directive 2010/30/EC,
 - This appliance also complies with:
 - decree No. 92-1271 (and its modifications) relating to certain refrigeration fluids used in refrigeration and air conditioning equipment. - regulation 842/2006 of the European parliament on certain fluorinated greenhouse gases.

 - the standards relating to the product and the testing methods used: Air-conditioners, refrigeration units and heat pumps with compressor driven by electric motor for heating and refrigeration EN 14511-1, 14511-2, 14511-3, and 14511-4.
 - standard EN 12102: Air-conditioners, heat pumps and dehumidifiers with compressor driven by electric motor. Measurement of airborne noise. Determination of acoustic power level.

Keymark Certification :

012-013 - Loria 6004 / 012-014 - Loria 6006 / 012-015 - Loria 6008



This unit is identified by this symbol. It means that all electrical and electronic products must not be included in household waste.

A specific recycling system for this type of product has been set up in European Union countries (*), Norway, Iceland and Liechtenstein. Do not try to dismantle this product yourself. It may have damaging effects on your health or on the environment.

- Reprocessing of the refrigerant, lubricant and other parts may be performed by a qualified installer in compliance with the local and national legislation in force.
- This unit must be recycled by a specialised service and in no case may it be thrown away with household waste, rubble or in a landfill.
- Please contact your installer or local representative for more information.
- * Depending on the national regulations of each member state.

Date of commissioning: Address of your heating installer or customer service.



atlantic-comfort.com

Société Industrielle de Chauffage SATC - BP 64 - 59660 MERVILLE - FRANCE